

MODEL-1950

PROM PROGRAMMER OPERATION MANUAL

Preface

For our valued customers

Thank you for purchasing Minato Gang Programmer M1950.

Please read this operation manual before operating M1950.

In order to use it safely and to fully utilize the performance of M1950, we strongly suggest you to read this operation manual.

Revision

M1950-016A-K0 2006/06/15 Rev. 1.00

M1950-016A-K1 2009/07/30 Rev. 2.00

Outline

Outline of the product

M1950 gang programmer is designed to target high-density device with fast speed and large standard 512 Mbyte (4 Gbit) memory. M1950 can program 16 pieces of IC simultaneously.

M1950 supports not only RS232C, but also USB and Compact Flash as interfaces. These interfaces are ideal for FA line where flexibility is required.

In spite of fast speed, it has many features to ensure safe and stable programming.

Key features

- Fast operating speed
- Standard 4 Gbit buffer memory
- Memory is expandable to 256 Gbit.
- Supporting various devices

Specifications

Simultaneous programming

Maximum 16 pieces of IC at once

Display

40characters x 4 lines LCD panel

2 color LED lamp on each socket

Buffer Memory

Standard 4 Gbit (Maximum 256 Gbit)

Interface

USB Interface

USB Rev.2.0 compliant

Serial Interface

RS232C (Standard)

Operating Temp.

5 - 35

Power Supply

AC100 - 240 V

50 - 60 Hz

Power Consumption

200 VA Max

Fuse

3.15 A

Size

W: 380 mm

D : 410 mm

H: 150 mm

Weight

9 kg

Warranty

Warranty

1. Please check with local distributor for the warranty.
2. Minato cannot provide local warranty for the product that is purchased in Japan and delivered to overseas.
3. We strongly suggest you to keep the original package in case of maintenance service.

Exempt of warranty

The following items are not a part of the warranty of M1950.

1. IC and data to program
2. Direct and indirect cost due to damage of M1950
3. M1950 purchased in Japan and brought to overseas
4. Damage of any direct and indirect cost due to use of third party items (example: adapter, software) on M1950
5. Repair or modification of M1950 by unauthorized party
6. Any damage due to misuse of M1950
7. Version up of M1950

Maintenance of M1950

M1950 Version-up (Device/Software support)

Version-up to add new IC support is not free of charge even within warranty period.



For safe use of M1950

Caution on safety

In this operation part of manual, caution marks are described to use gang programmer M1950 safely.

If any misuse of M1950 can be a cause of the damage of your assets
And harms on you, the following caution marks are indicated.

Explanation of caution marks

 Warning	If you do not follow the instruction of this operation manual, it can cause death or serious injury.
 Caution	If you do not follow the instruction of this operation manual, it can harm yourself or cause damage on your assets.



Warning



Compulsion

Please follow the warning and caution instructions of Minato Electronic Inc.



Do not dismantle

Do not dismantle product that can cause a fire or electric shock.



Unplug

If you see any smoke or sense any bad smell, unplug the power cable immediately.

If you do not do so, that can cause a fire or electric shock.



Unplug

If the product is dropped or damaged, unplug the power cable immediately.

If you do not do so, that can cause a fire or electric shock.



Unplug

If any liquid or foreign objects are got into the product, unplug the power cable immediately.

If you do not do so, that can cause a fire or electric shock.



Caution



Compulsion

Operator who had read this operation manual and understand the operation should use M1950.

Wrong operation can cause to damage this product or IC device.



Compulsion

In order to avoid shock of electrostatic, discharge electrostatic before operating M1950.

If you do not so so, that can damage this product or IC device.



Compulsion

Clean up the surface of M1950, socket adapter and air filter.

Assumulated dusts can cause a fire or damage of M1950.



Compulsion

Do not program IC device when Empty Socket (redLED) is indicated.

If you do not do so, IC device is heated up and can cause damage of IC device or M1950.



Compulsion

To judge PASS/ FAIL, please check the check-sum.

Bad devices can be mixed with programmed devices.



Compulsion

Caution for accessories.

Standard cable complies with Japanese regulation.

If you are going to purchase M1950 in Japan and going to bring it to overseas, please follow the safety standard of the country.

CONTENTS

PREFACE.....	3
For our valued customers.....	3
Revision.....	3
Outline	4
Key features.....	4
Specifications.....	5
WARRANTY	6
Warranty	6
Exempt of warranty	6
MAINTENANCE OF M1950	7
M1950 Version-up (Device/Software support)	7
FOR SAFE USE OF M1950	8
Caution on safety	8
Explanation of caution marks	8
MODEL-1950 PACKING LIST	18
NAME OF EACH PART AND ITS FUNCTION ON M1950.....	19
DISPLAY PANEL	20
KEY SWITCH	20
SOCKET UNIT #	21
SOCKET UNIT CONNECTOR	21
OPTIONAL ITEMS.....	24
SOCKET UNIT	25
SOCKET ADAPTER.....	28
EXPLANATION OF EACH KEY SWITCH.....	30
START	30
RESET	30
COPY.....	30
ERASE.....	30
BLANK	30
PROG	30
VERIFY	30
CONT.....	31
MODE	31
COM	31
DEV	32
▲▼▲▼.....	32
BASIC OPERATION.....	33
INSTALLATION AND TO TURN ON THE POWER	34
SELECT A DEVICE	35
COPY DATA IN THE DEVICE INTO THE BUFFER MEMORY To COPY DATA IN A DEVICE INTO THE BUFFER OF M1950. Use COPY Key.....	36
ERASE DATA IN A DEVICE	38

TO EXECUTE BLANK CHECK OF A DEVICE	40
VERIFY DATA.....	42
PROGRAM DATA	44
CONTINUOUS OPERATOIN	46
USE <u>MODE</u> MENU OF M1950.....	49
DEVICE FUNC	50
<u>PAE MODE</u>	51
Clear PAE mode	51
Single PAE mode	51
Multi PAE mode	52
<u>VERIFY MODE</u>	53
Verify count.....	53
<u>PROTECT MODE</u>	54
No Operation	54
Protect only.....	54
Unprotect/Protect	54
<u>MONITOR MODE</u>	55
<u>READ VCC</u>	56
<u>FUNCTION MODE</u>	57
Contact check	57
ID Check.....	57
<u>REPEAT MODE</u>	58
OFF	58
One Fail STOP.....	58
all Fail STOP.....	58
<u>MODULE PARAMETER</u>	59
I/O COMMAND.....	60
Transfer [IN].....	60
Transfer [OUT]	60
CF CARD	61
BUFFER OPERATION.....	62
<u>BUFFER INIT</u>	63
<u>BUFFER SWAP</u>	64
Swap [BYTE]	64
Swap [WORD]	65
<u>PROTECT SETTING</u>	66
<u>BUFFER DUMP/EDIT</u>	67
<u>CHECK SUM</u>	68
<u>FAST SUM</u>	69
SYSTEM CONFIG	70
<u>COM SETTING</u>	71
BAUD RATE	71
DATA BIT	71
PARITY.....	71
STOP BIT	71
FLOW CONTROL	71
<u>FORMAT SELECT</u>	72

FORMAT.....	72
I/O CHANNEL SELECT	73
Monitor channel	73
Data I/O channel	73
M1950 VERSION	74
USB SETTING.....	75
ID CODE.....	75
REMOTE SETTING	76
ECHO	76
PROMPT	76
ACK/NCK.....	76
BUZZER.....	76
OTHERS MODE	77
Selfcheck.....	77
CRC mode.....	77
BUZZER	77
REMOTE EMULATION	78
SET START COUNT	79
SYSTEM UPDATE.....	80
REMOTE	81
EACH OPERATION PROCEDURE.....	82
TO SET PROGRAMMING ADDRESS <SINGLE PAE MODE>	83
TO SET AUTO PROGRAMMING ADDRESS SERACH <MULTI PAE MODE>	85
TO TRUN OFF PAE MODE <CLEAR PAE MODE>	87
TO SET PROTECT SETTING <PROTECT MODE>.....	88
ENABLE PROTECTION PER EACH SECTOR <PROTECT SETTING>	89
TO SET VERIFY VOLTAGE <READ VCC>	90
TO SET VERIFY PATTERN <VERIFY MODE>.....	91
TO ENABLE CONTACT /IC CHECK <FUNCTION MODE>	92
SET REPEAT OPERATION <REPEAT MODE>.....	93
BUFFER MEMORY	94
TO INITIALIZE BUFFER MEMORY <BUFFER INIT>	95
TO EDIT BUFFER DATA <BUFFER DUMP/EDIT>	96
SWAP DATA IN THE BUFFER IN EACH BYTE <BUFFER SWAP>	98
TO SWAP DATA IN THE BUFFER IN EACH WORD <BUFFER SWAP>	99
OTHER OPERATIONS.	100
TO CHECK THE VERSION OF M1950 <M1950 VERSION>	101
TO HAVE CHECK SUM DISPLAYED <CHECK SUM>	102
TO HAVE FAST SUM DISPLAYED <FAST SUM>	103
TO SKIP SELF CHECK <SELF CHECK>.....	104
TO CHANGE THE SETTING OF CRC CHECK <CRC MODE>.....	105
TO SET A BUZZER SETTING <BUZZER>	106
OPERATION OF CF CARD	107
TO SEND DATA FROM CF CARD TO M1950.....	108
TO SEND DATA FROM THE BUFFER OF M1950 TO CF CARD	109
BEFORE CONNECTING TO EXTERNAL DEVICE.....	111

USB SET UP GUIDE	112
TO SET RS-232C INTERFACE <COM SETTING>	114
CAUTION DURING REMOTE OPERATION	115
ID CHECK SETTING DURING FUNDAMENTAL OPERATION <REMOTE EMULATION>	116
SET FORMAT PATTERN <FORMAT SELECT>	117
TO SET INPUT / OUPUT PORT <I/O CHANNEL SELECT>	118
FOR DATA TRANSFER <I/O COMMAND>	119
Read data through external device("Transfer IN")	119
To output data to an external device ("Transfer OUT")	120
REMOTE OPERATION OF M1950	121
SETTING CONDITION OF REMOTE MODE <REMOTE SETTING>	122
TO MAKE M1950 IN REMOTE<REMOTE>	123
Execution by operation panel	123
Execution of remote mode by a command	124
FORMAT OF REMOTE COMMAND	126
SYMBOLS USED IN THIS CHAPTER (REMOTE MODE)	127
DISPLAY THE RESULT OF COMMAND	128
SETTING OF REMODE MODE CONDITION <RMD>	130
END OF REMODE MODE <E> <BY>	132
TERMINATION COMMAND <CTRL+D>	133
HELP TO OUTPUT THE LIST OF COMMANDS <H>P	134
DEVICE SELECTION COMMAND <N> <DV>	135
TO EXECUTE COPY MODE <OP> <CP>	136
TO EXECUTE ERASE MODE <Z> <ER>	137
TO EXECUTE BLANK MODE <BL>	138
TO EXECUTE PROGRAM MODE <W> <PG>	139
TO EXECUTE VERIFY MODE <V> <VF>	140
TO EXECUTE CONTINUOUS MODE <OT> <CT>	141
SETTING ID CHECK <SIG>	142
PRE-CHECK COMMAND <CK>	143
ADDRESS AREA SETTING COMMAND <MD> <PAE>	144
ADDRESS AREA SETTING COMMAND <MD> <PAE>	146
SETTING DATA FORMAT FOR TRANSFER <S> <DF>	148
BUFFER MEMORY SIZE OUTPUT <BS>	150
FIRMWARE VERSION OUTPUT <REV>	151
BUFFER MEMORY DATA DISPAY <L> <LS>	152
CHECK SUM DISPLAY(FOUR DIGITS) <BO> <CS>	153
CHECK SUM DISPLAYED (8 DIGITS)<BO8> <CS8>	154
TO INITIALIZE BUFER MEMORY <F> <INI>	155
DATA SEARCH (MATCH) COMMAND <SCH>	156
DATA SEARCH (NO MATCH) COMMAND <UNS>	157
DATA TRANSFER COMMAND <T>	158
SERIAL I/F DATA OUTPUT <P> <PL> <WD>	159
SERIAL I/F DATA INPUT <RL>	161
SERIAL I/F DATA INPUT <RD>	162
TO CHANGE PROTECT MODE SETTING <PCH>	163
PROTECT DATA SERIAL I/F OUTPUT <WP>	164
PROTECT DATA SERIAL I/F INPUT <RP>	165
LIST	166

LIST OF REMOTE COMMAND.....167

LIST OF SPECIAL CHARACTERS168

LIST OF ERROR MESSAGE169


LIST OF ERROR MESSAGE OF REMOTE MODE170

EXPLANATION OF QUICK REFERENCE MANUAL172

QUICK REFERENCE.....173

MODEL-1950 packing list

The following indicates the list of packing in the box of M1950. Please check if you receive all items.



M1950 main unit : 1 set




AC Cable : 1 piece



CD : M1950 Operation manual /USB driver : 1 piece

Name of each part and its function on M1950


In order to operate M1950 properly, please understand the function of each part and its name. The details are described in following pages.



Display Panel


40 Characters x 4 lines LCD

Operation setting, operation mode are displayed on this LCD.




Key Switch

Stand-alone operation of M1950 is carried out by these operation keys. Please refer to The Operation of Each Key of M1950 for detail.



Socket Installation Area



Socket Unit

The number is assigned according to the position of the connector
In this operation manual, # indicated the number of the socket unit.

(Example)

Socket unit 2 is described as #2.

Socket Unit Connector

This is the connector to install optional socket unit.


LED Lamp (PASS/FAIL Indicator)

Different color is lit according to the results of the operation.

PASS: Green in color

FAIL: Red in color

Rear Panel



Power Connector

This is an AC power supply connector with (3.15A) fuse.

Power Supply Switch

This is a power supply switch

USB Connector

This is a USB connector.

RS-232C Connector

This is a serial interface connector RS-232C).

Air Inlet

This is an air inlet for cooling fan of M1950.

Do not cover it up.

Serial Number


This is a serial number label unique for each M1950. When you make a service call, this number is required.

Revision Number

This is a revision number label. When you make a service call, this number is required.

Compact Flash Slot

On the right side of M1950, there is a button to eject CF card.




Optional Items


The following items are available as optional accessories for M1950.

Socket unit are required to program IC on M1950.

Socket Unit



Socket Adaptor



CD



Remote Control Software
XPROM

**Minato Electronics Inc also carry Automatic handler for M1950.
Please contact to Minato or our distributor for detail**

Socket Unit

We offer various types of socket units. This page describes how to install each socket unit and its direction on M1950.

For installation of other socket, please contact to Minato or our distributor.

Various kinds of socket unit

The followings are four major type of socket unit.

SU50-48DP

This socket unit is targeted for DIP type device.

It is good to install many different types of socket adapters on it.

SU50-48TS

This socket unit is targeted for 48TSOP type IC.

SU50-xxxx

This socket unit is targeted for other type of special package that can not be supported by other standard type of socket unit described in this page.

Various types of Socket Adapters


Some adapters of M1940 can be used on M1950.

To use it on M1950, SU50-48DP is required.

Please refer to Socket Adapter for detail.

Direction to install socket unit

This page describes the direction to install socket unit onto M1950.



Lock Lever (Open/Close Lever)

To install device, lever must be up (open). To fix device, lever must be up (close). When lever is up, M1950 is ready with other setting made.

Devcie Socket

By pressing down device socket to open or close, TSOP, BGA type device other than DIP type can be set.

Slit of PCB

Check the slit to find the direction of socket.

Direction to install socket unit

Please follow the direction as described below.

SU50-48DP Socket Unit


Lock lever must be facing front.

SU50-48TS Socket Unit

SU50-xxxx marking must be correct as indicated
In the following drawing.

SU50-xxxx Socket unit

Slit of PCB must be positioned in lower right.



Socket Adapter


This chapter describes socket adapters that can be used on M1950.

Definition of socket adapter

1. This chapter describes socket adapters targeted for M1950.
2. Some adapter of M1940 can be used on M1950 by version up of firmware.

Caution

To use optional socket adapter, optional socket unit SU50-48DP is required.
SU50-48DP enables to cover from DIP to various types of adapters.



Explanation of each key switch

This page describes each key switch of M1950.

START

START Key

To execute set function

RESET

RESET Key

This key is to stop current function running. This key is also good to cancel a function set.

COPY

COPY Key

This key is to transfer data from set device on socket #1 to the buffer memory of M1950.

ERASE

ERASE Key

This is to erase data of electrically erasable ROM (such as EE-PROM, Flash) which is placed on socket #1 to #16.

BLANK

BLANK Key

This is to carry out Blank Check of ROM that is placed on socket #1 to #16.

PROG

PROGRAM Key

This is to program data of the buffer memory to ROM that is placed on socket #1 to #16.

VERIFY

VERIFY Key

This is to verify the data of the buffer memory and data of ROM that is placed on socket #1 to #16.

The difference of four verify function is as follows:

	Vcc	Data line
VERIFY1	VccL(Verify_L)	Pull-up to Vcc
VERIFY2	VccL(Verify_L)	Pull-down to GND
VERIFY3	VccH(Verify_H)	Pull-up to Vcc
VERIFY4	VccH(Verify_H)	Pull-down to GND

VccH: Voltage for device (High setting value)

VccL: Voltage for device (Low setting value)

Depending on the types of device, there are two patterns.

Type	VERIFY Pattern			
FLASH		VERIFY2	VERIFY3	
EP-ROM/ EE-PROM	VERIFY1	VERIFY2	VERIFY3	VERIFY4

Targeted device is 3.3v to 1.4v

CONT

CONTINUOUS Key

This is to start continuous function on ROM places on socket #1 to #16.

MODE

MODE Key

The menu is open up when this key is pressed.

If this key is pressed in Read VCC menu, set values are initialized.

COM

COMMAND Key

This is to change voltage, address. It is good only for changes these values.

How to use

When COM key is pressed under the menu of changing address, black square cursor is indicated. Then you can change the value by up and down key. Left and right keys enables to move the cursor to the left and the right.

When you finished to change address, please COM or START once again to get out of this function. Then black square cursor is disappeared. By up or down key, you can move to other function.

(Example) Single PAE Setting

Single PAE Setting		OK → [START] key
Start	[0000000]	Black square cursor
End	003FFFFFF	
Buffer	00000000	

DEV

DEVICE Key

This is to select a device.

By pressing this key, device selection menu is open up. Then you can select a device. During other operation, by pressing this key enables you to go back to former menu.

ENT

ENT Key

This is to confirm the selction.



Arrow key

This is to change the address, voltage or to move cursor in the menu.

Basic Operation

This chapter describes the operation of the following.

- Installation and to turn on power
- To select proper adapter
- To COPY in the device
- To ERASE programmed data in the device
- To carry out BLANK CHECK
- To carry out VERIFY
- To PROGRAM data into a device
- To carry out CONTINUOUS mode

M1950 has designated function allowing you to execute each function with a push of key switch. \

Installation and to turn on the power

This chapter describes required environment of working area and the procedure to turn on the power. Please make sure that there is not NC machine with motors or electric welding machine which generates noise.


Caution prior to operation

- 1. M1950 should be leveled and should be installed in an area where there is no vibration.
- 2. Designated power inlet for AC power cable is strongly recommended.
- 3. 3P connector with ground is recommended.
- 4. After making sure that the power of M1950 is OFF, connect the AC cable to the power inlet of M1950 which is located on the backside of the M1950.
- 5. Do not set devices or socket adapters when you turn on the power of M1950.

Operation Procedure


Making sure nothing is installed on the socket, turn on the power switch of M1950 that is located on the backside of M1950.

Self diagnostic test is automatically executed.




Wait for one minute to have version displayed.

The following indicates M1950 is working correctly.



After recalling the device code formally set, initial display appears

Initial display



Select a device

Use **DEV** key to select a device.

Operation procedure

When **DEV** key is pressed,
Manufacture Select is displayed.

Manufacture select			CD:01----
[ALLIANCE]	AMD	AMIC	
Asahikasei	ATMEL	BRIGHT	
Casio	Catalyst	CYPRESS	

Select a device supplier by arrow key and press **ENT** key to confirm.

Manufacture select			CD:0E----
FUJITSU	Renesas (H)	HOLEK	
HYNIX	ict	[intel]	
ISSI	LETech	MACRONIX	

Then density selection is displayed.
Select a density and press **ENT** key to confirm.

Capacity select					CD:0E0B--
1M	2M	4M	8M	16M	
32M	64M	128M	[256M]	512M	
1G	2G	4M	8G	OTHER	

Then device selection is displayed.
Select a device and press **ENT** key to confirm.

Device Select		CD:0E0BA4
[RD38F3352LLZD]	PF38F4050LOYBQ2	

Then setting is displayed.
Make sure that correct device is selected.

Select Device	CD:0E0BA4
intel	256M/16bit
RD38F3352LLZD	
OK-> [START] key	

If it is correct, press **START** key. Then buzzer sounds and goes back to initial display.
In the LCD, selected device is displayed.

BLANK	NO	Σ256G/16b
intel	RD38F3352LLZD	CD:0E0BA4

COPY data in the device into the buffer memory
 copy data in a device into the buffer of M1950. Use **COPY** Key.

To


Caution prior to operation

1. Check if the check-sum is correct to verify if **COPY** is completed correctly.
2. Do not set a master device on other socket # than #1.
3. If the direction device is not correct, that could damage the device.
4. COPY enables data read and copy only from the device set on socket #1.


Operation procedure of COPY mode

1. Set device code.
2. Set a device on socket # 1.
3. Press **COPY** key.
4. Press **START** key.

When **START** key is pressed, COPY is executed. If COPY is successfully completed, green LED is lit. If it is failed, red LED is lit. When LED is green, check-sum is displayed on LCD.



COPY MODE WORK FLOW CHART



ERASE data in a device

Use **ERASE** key to erase data stored in electrically erasable ROM (such as EE-PROM, Flash)

Caution prior to operation


If Erase is executed on the device for which CONTACT is displayed on the socket unit, that may damage the device. Please remove the device of such a socket before executing Erase.

Operation procedure of ERASE mode

1. Set a device code
2. Press **ERASE** key
3. Set devices for erase on socket #1 to #16
4. Press **START** key
When all devices are set on socket #1 to #16, ERASE is automatically executed. If there is the socket without a device, CONTACT is displayed on LCD. Then red LED lit on the socket without a device. Then operation is fault.
5. Press **START** key once again to execute Erase operation.
6. At the end of Erase, PASS/FAIL is indicated by LCD and the color of LED.

ERASE MODE WORK FLOW

This page describes Erase mode work flow of M1950.



To execute Blank Check of a device

To execute Blank Check of a device, use **BLANK** key.

Caution prior to operation


If Blank Check is executed on the device for which CONTACT is displayed on the socket unit, that may damage the device. Please remove the device of such a socket before executing Blank Check.

Operation procedure of BLANK mode

1. Set a device code
2. Set devices for blank check from socket #1 to #16.
3. Press **BLANK** key.
4. Press **START** key.
If there is the socket without a device, CONTACT is displayed on LCD. Then red LED lit on the socket without a device. Then operation is fault.
5. Press **START** key to continue Blank Check Operation.
6. At the end of Blank Check, PASS/FAIL is indicated by LCD and the color of LED.

BLANK MODE WORK FLOW

The following describes Blank Mode Wrok FLOW



Verify Data

This function is to verify data between the master ROM and the buffer memory of M1950. It is recommended to use several different read setting to verify data.

Caution prior to operation


If Verify is executed on the device for which CONTACT is displayed on the socket unit, that may damage the device. Please remove the device of such a socket before executing Verify.

Operation procedure of Verify mode

1. Set a device code.
2. Press **VERIFY** key.
3. Set devices for verify from socket #1 to #16.
4. Press **START** key.
If there is the socket without a device, CONTACT is displayed on LCD. Then red LED lit on the socket without a device. Then operation is fault.
5. Press **START** key to continue Verify Operation.
6. At the end of Verify, PASS/FAIL is indicated by LCD and the color of LED.

VERIFY MODE WORK FLOW

The following is the work flow of verify mode of M1950.



Program Data

This function is to program data from the buffer memory of M1950 to devices.

Caution prior to operation


If Program is executed on the device for which CONTACT is displayed on the socket unit, that may damage the device. Please remove the device of such a socket before executing Program.

Operation procedure of Program mode

1. Set a device code.
2. Press **PROG** key.
3. Set devices for Program from socket #1 to #16.
4. Press **START** key
If there is the socket without a device, CONTACT is displayed on LCD. Then red LED lit on the socket without a device. Then operation is fault.
5. Press **START** key to continue Program operation.
6. At the end of Program, PASS/FAIL is indicated by LCD and the color of LED.

PROGRAM MODE WORK FLOW

The following is the wrok flow of program mode of M1950.



Continuous Operatoin

CONT key execute sequential operatoin of ERASE, BLANK, PROGRAM and VERIFY. M1950 automatically execute these functions sequentially.

The function work flow is different between electrically erasable ROM such as Flash/EE-Prom (by Erase mode of M1950) and EP-ROM which can not be erased electrically.

Caution prior to operation


If Continuous is executed on the device for which CONTACT is displayed on the socket unit, that may damage the device. Please remove the device of such a socket before executing Continuous.

Operation procedure of CONTINUOUS mode

1. Set a device code.
2. Press **CONT** key.
3. Set devices for Continuous operation from socket #1 to #16.
4. Press **START** key.
If there is the socket without a device, CONTACT is dispalyed on LCD. Then red LED lit on the socket without a device. Then operation is fault.
5. Press **START** key to continue Continuous operation.
6. At the end of Continuous operaotin, PASS/FAIL is indicated by LCD and the color of LED.


CONTINUOUS mode work flow 1(when a device is a FLASH/EE-PROM)

M1950 The following is the work flow of Continuous mode of M1950.



CONTINUOUS mode work follows 2(when a device is an EP-ROM)

The following is the work flow of continuous mode of M1950.



Use **MODE** menu of M1950

Most of operations as a PROM programmer can be covered by basic function. M1950 is utilizing additional functions under the **MODE** key menu.

Device func

Device func menu includes the following functions.

- PAE mode
- Verify mode
- Protect mode
- Monitor mode
- Read VCC
- Function mode
- Repeat mode
- Module Parameter


PAE mode

Under the normal mode, M1950 access to all data address of a device. By using this mode, M1950 access to only targeted area.

Clear PAE mode

This is to set or cancel the set value of Single PAE and Multi PAE.

Single PAE mode



You can manually set one start address and one end address.

Set address is different depending on the programming mode of a device. Although there are three different types of programming mode, M1950 automatically detects the mode.

	Device start Address	Device end Address	Buffer start Address
Byte programming	Every 16 byte	Every 16 Address	Every 16Address
Word programming	Every 8 word	Every 8 Address	Every Even Address
Multi-byte/multi-Word programming	Every256 byte/128 word	Every 256 byte /128 word	Every 256 byte /128 word

Remarks: Every 16 byte change on M1950

Multi PAE mode

Most of Flash memory takes care of memory area by sectors.

When Multi PAE mode is used, M1950 automatically targets the programming address by using the sector inf. of the device and data in the buffer. (Multiple start and end address is automatically set).

M1950 automatically detect FF'hex data in the buffer memory. When there is any data other than FF'hex in the buffer memory of the set sector, targeted sector of the device is programmed. When there is only FF'hex data in the buffer memory of the set sector, all address of the set sector is skipped.

Skip is valid only for PROGRAM. In case of COPY, ERASE, BLANK and VERIFY, all address area is targeted.

BUFFER MEMORY		ERASE BLANK	PROGRAM	COPY VERIFY
	FF'hex			
1	FF'hex			
2				
3				
4	FF'hex			
5				
6	FF'hex			
7				
8	FF'hex			
9	FF'hex			

	Valid Data
	Valid Area

Verify mode

You can set execution pattern of Verify mode.

Verify count

There are three patterns of Verify count. You can choose either one of them.

(The detail of Verify is described in [Verify](#))

Please see the detail of each selection.

Default

Executing in sequence of Verify1, Verify2, Verify3 and Verify4.

However, it also depends on the specification of the device selected.

2Times

Executing in sequence of Verify2 and Verify3.

However, it also depends on the specification of the device selected.

1Time

Executing only verify 3

It does not depend on the specification of the device selected.

Remarks

Default execution pattern is different between EE-ROM/EP-ROM and FLASH.

Verify count		Executon pattern	default
Default	EP-ROM	Verify1 Verify2 Verify3 Verify4 Depends on the device	default
	EE-PROM	Verify1 Verify2 Verify3 Verify4 Depends on the device	
	FLASH	Verify2 Verify3 Does not depend on the device	
2Times		Verify2 Verify3 Depends on the device	
1Time		Verify3	

Protect mode

Some FLASH type device features protect function to protect data. Protect inf. is stored in special area other than data area. M1950 has three functions on the operation of protect mode.

No Operation

This is the standard mode under normal operation. Under this mode, M1950 does not access to protect area by the fundamental operation such as (COPY, BLANK, PROGRAM, VERIFY)
When this mode is selected, NO is displayed on the center of the first line of LCD.

Protect only

Under this mode, M1950 access to only to protect area. Please make a note that it does not access to data area.
When this mode is selected, PO is displayed on the center of the first line of LCD.

Unprotect/Protect

Under this mode, M1950 erase protect inf. before executing PROGRAM mode. Then M1950 program protect inf.
When this mode is selected, UP is displayed on the center of the first line of LCD.

Monitor mode

This is a menu to set ON/OFF for the output of certain device to the external device.

Remark: Only NAND device is supported as certain device.

Caution


Setting only Monitor mode does not enable to output to external device.

The following setting is required to enable output to external device.

1. Set output port for external device (select either COM or USB under I/O channel select)
2. Select remote mode on M1950. On the Remote Select item of Remote menu, set either COM or USB as an output port to external device (it must be same port as the selection of I/O channel select).

Remarks: Selection of 1 and 2 must be the same.

Work flow chart



Read VCC

Voltage applied to the device during read operation can be changed. Voltage for READ operation means supply voltage during BLANK and VERIFY operation. It does not apply to read voltage of COPY.

For VERIFY, maximum and minimum voltage must be set. Verify_H is the maximum voltage applied the device. Verify_L is the minimum. When Verify_H, Verify_L are not set by this operation, default value is applied.

Verify_H = Maximum value

Verify_L = Minimum value

Read vcc operation display

Read vcc #copy:	PS1=2.9	PS2=0.0	PS3=0.0
BLANK	[2.90v]	0.00v	0.00v
VERIFY-L	2.90v	0.00v	0.00v
VERIFY-H	2.90v	0.00v	0.00v

PS1/PS2/PS3 displayed on Read VCC LCD is internal supply voltage of the programmer.

Function mode

Under function mode, contact and ID check are carried out during COPY, BLANK, PROGRAM, VERIFY, ERASE and CONT execution. Contact check, ID check can set as ON/OFF.

Contact check

Contact device check is to detect if the position of device is correct or the direction is correct or the device is not damaged. Since there are various specification of devices, some devices including microcontroller does not allow to carry out a contact check. For such device, contact mode setting must be OFF.

ID Check

ID check function is to judge whether selected device of the device select operation of M1950 and the actual device matches or not.

To use a compatible code (different part number of device, but same code or algorithm can be applied by the instruction of Minato Electronics Inc.), this function must be OFF.

When device code is set or changed, ID check function changed to default (For standard device, default of ID check function is ON).

Repeat mode

This function executes a set function such as Verify in repeat.
It is used to check continuous running test of devices.

Explanation of Repeat mode

OFF

Repeat function is not valid.

One Fail STOP

If one device is Fail, operation is stopped.

All Fail STOP

If one of device is pass, operation continues.
(When all devices are fail, operation stops)

Module Parameter

This function is not supported at this moment.

I/O command

I/O command is a menu for setting input/output data.

For data transfer, USB/RS-232C must be used. For detail of the setting, please refer to [input/output port setting](#).

Data Transfer Mode

Transfer [IN]

Data Serial In (Data SR In)

This is a data input mode

Make serial I/F of M1950 ready and enable sending data to the buffer memory in the set data format.

Transfer [OUT]

Data Serial Out (Data SR Out)

This is a data output mode.

Output data in the buffer memory of M1950 through serial I/F in set format.

CF card

M1950 is equipped with CF card for data DOWN LOAD and UPLOAD.

Caution

Do not remove CF card from the slot during data transfer. It may damage M1950.

Buffer operation

Buffer operation menu describes the following functions.

- Buffer init
- Buffer swap
- Protect setting
- Buffer DUMP/EDIT
- Check sum
- Fast sum

Buffer init

This function is to fill the buffer memory of M1950 by a certain data. After turning on the power of M1950, buffer memory of M1950 is initialized by filling up FF(hex).

M1950 offer four initialize pattern.

All FFH

Initialize with FF(hex)

All 00H

Initialize with 00(hex)

Test Pattern A

Initialize by 03, 06, 0C, 18, 30, 60, C0”(hex) in repeat


Test Pattern B

Initialize by 00, 00, FF, FF, 00, 00, FF”(hex) in repeat

Buffer swap


Swap [BYTE]

This function is to swap the data in the buffer memory of M1950 in each byte.



Swap [WORD]

This function is to swap the data of the buffer memory of M1950 in each word.



Protect setting

Protect setting is valid only when sector protect of the device is supported on M1950.

If [.] is displayed on LCD, protect is OFF. When [*] is displayed, protect is ON.

Use **ENT** key to turn ON/OFF the protection.

Protect data in this operation is applied when protect mode is set.

Buffer DUMP/EDIT

M1950 allow you to display, edit the data in the buffer on LCD.

Edit mode directly access to the data of the buffer memory. Please be cautious to use this function.

Check sum

This function is to calculate sum, Exclusive OR and CRC (in 16 bits or 32 bits) of the data stored in the buffer memory of M1950.

In M1950, most reliable CRC check method is added.

During the standard operation, Check sum (4 digits) and EXOR are displayed. It is used when Buffer data is changed or data is loaded.

The calculation method is as follows.

Check Sum:

Bit width 8Bit fixed
Over flow round down at 9th digits
Digits 8 digits in Hex

EXOR (Exclusive OR) :

Bit width 8Bit fixed
Digits 2 digits in Hex

CRC:

Calculation method CRC16: $X^{16} + X^{15} + X^2 + 1$
 CRC32: $X^{32} + X^{26} + X^{23} + X^{22} + X^{16} + X^{12} + X^{11} + X^{10} + X^8 + X^7 + X^5 + X^4 + X^2 + X + 1$
Digits 8 digits in Hex

Example of calculation

Data [Hex]	Check Sum [Hex]	EXOR[Hex]
AA	0000AA	AA
55	0000FF	FF
AA	0001A9	55
55	0001FE	00
AA	0002A8	AA
55	0002FD	FF
AA	0003A7	55

Check sum of other Minato gang programmer is rounded down at 5th digits as it only displays up to 4th digits.

Fast sum

This function is to calculate sum of the buffer area in fast speed by hardware.
Address Fast sum menu allow you to change in 16 byte (1st digit is fixed).

System config

System config menu describes the following functions.

- COM setting
- Format select
- I/O channel select
- M1950 Version
- USB setting
- Remote setting
- Others mode
- System update

COM setting

In this menu, you can select and set the condition of RS-232C data transfer.
The condition must be matched between M1950 and external device for RS-232C interface.

Please use straight cable between M1950 and PC that is commonly available in the market.

BAUD RATE

Select and setting baud rate

DATA BIT

Select and setting character bit

PARITY

Select and setting parity bit

STOP BIT

Select and setting stop bit

FLOW CONTROL

Select and setting flow control

Vaild communication setting of M1950

Item	Selection	Deault
BAUD RATE	[9600bps] , [19200bps] , [38400bps] , [57600bps] , [115200bps]	[115200bps]
DATA BIT	[7bit], [8bit]	[8bit]
PARITY	[NON] , [EVEN] , [ODD] ,	[NON]
STOP BIT	[1bit], [2bit]	[2bit]
FLOW CONTROL	[XON/OFF] , [NO CTRL]	[XON/OFF]

Format select

By format select, data format to make interface with external device can be set.

FORMAT

Before sending data, set the format for the transfer. Set the format according to the format set on M1950.

Format that can be set on M1950

Item	Selection	Default
FORMAT	[NO-FORMAT(BIN)] ,[MINATO(MIN)] ,[INTEL-HEX(HEX)] [MOTOROLA-S(MOT)]	[MOTOROLA-S(MOT)]

I/O channel select

By I/O channel select, the port to interface making interface between M1950 and an external device can be set. Choose one from the followin three selections.

COM

It allows data transfer through RS-232C port.

USB

It allows data transfer throught USB port.

OFF

When neither port is used
(When M1950 is operated with no interface)

Monitor channel

It is to make a selection of output port where devices inf. are displayed externally.

Data I/O channel

It is to make a setion of port for data transfer.

Item	Selection	Default
Monitor channel	[OFF] ,[COM] ,[USB]	[OFF]
Data I/O channel	[OFF] ,[COM] ,[USB]	[OFF]

M1950 Version

It is to check and display the firmware version of M1950

USB setting

ID CODE

It is a menu to input USB recognition code.

When more than 2 units of M1950 are connected to one PC through USB hub, different ID code should be set on each M1950.

Remote setting

It is to set the condition of remote mode for interface between external device and M1950. There are two ways to make a setting. One way can be accomplished by the operation panel of M1950. The other way can be accomplished by remote mode. There are following settings.

ECHO

It is to set whether M1950 returns the code sent from external device or not. If the following special characters are included in the code sent from external device, M1950 will not simply make an echo back. In such a case, specified commands according to the characters are carried out.

ON

OFF

Select either ON or OFF.

PROMPT

When the command is completed, M1950 outputs Prompt to external device which is to inform that M1950 is ready to receive another input.

Select one prompt character out of the following three selections.

---- (No display of "#")

#

#CRLF (_cursor is displayed under "#")

ACK/NCK

It is to inform to external device whether received command of M1950 is valid or not.

It is to set ON/OFF of the reply (after #, A is displayed).

BUZZER

When M1950 is changed to remote mode, you can select either to sound a buzzer according to the results of remote command. M1950 or not.

However, PASS/FAIL buzzer of the result of the fundamental functions such as COPY, PROGRAM, etc sounds regardless of this setting.

ON

OFF

Select either ON or OFF.

(Operation method is described in [how to set remote mode condition](#))

Others mode

Selfcheck

Skip / No skip of self-check

When power is turned on, M1950 executes self diagnostic check.

Self-check can not be accomplished correctly if socket adapter (and IC) are mounted on M1950. It can damage the IC. If adapters and IC can not be removed from M1950 due to working environment (example auto handler), self-check function can be turned OFF.

Please do not leave M1950 with self-test OFF condition for a long period of time. Please turn on self-check function periodically to check M1950 is running properly.

No skip : all self-check function is ON(default settin prior to shipment)

Skip : self-check function related to socket adapter is OFF.

CRC mode

CRC MODE can display either 16 bit or 32 bit check.

The following is the calculation method of CRC.

16bit calculation mehtod

CRC16: $X^{16} + X^{15} + X^2 + 1$

32bit calculation method

CRC32: $X^{32} + X^{26} + X^{23} + X^{22} + X^{16} + X^{12} + X^{11} + X^{10} + X^8 + X^7 + X^5 + X^4 + X^2 + X + 1$

BUZZER

It is to enable a buzzer during operation or not.

KEY+FUNCTION

A buzzer sounds for a key operation and at the end of a function.

FUNCTION

A buzzer sounds only at the end of a function.

KEY

A buzzer sounds only for a key operation.

OFF

A buzzer sounds for OFF.

REMOTE EMULATION

It is a mode to specify whether ID check is valid or not during device operation command such as OP,VF,PG...

Since REMOTE EMULATION setting affects remote mode pre-check command and device operation command, it is recommended to check prior to getting into remote mode.

Selection

M1940 mode: ID check is in valid during COPY, BLANK, etc operation.
When operation commnd is completed, the result of PASS/FAIL is output.
ID check is carried out when CK command is executed.

M1895 mode: Device ID check is carried out during COPY, BLANK...etc operation.
The output inf. varies depending on the results of ID check (same as panel operation)

In case of ID check pass: Pass/FAIL is output at the end of an operation
(same as M1940 mode)

In case of ID check fail: It outputs the result of ID check and stop operation of M1950.
COPY, BLANK, ect operation is not executed.

Remarks: In M1895 mode status error is output and M1950 stops its operation when ID check error is detected.

SET START COUNT

It is to set a time to automatically start programming after all devices are mounted onto socket of M1950.

List of Others mode

Item	Selection	Default value
SELF CHECK	[NO_SKIP] [SKIP]	[NO_SKIP]
CRC MODE	[CRC32] [CRC16]	[CRC32]
BUZZER	[KEY+FUNCTION] [FUNCTION] [KEY] [OFF]	[KEY+FUNCTION]
REMOTE EMULATION	[M1940] [M1895]	[M1940]
SET START COUNT	[OFF] [0.1S]...[10.S]	[OFF]

System update

Version up of M1950

In order to add new device algorithm, version-up of firmware is required.

For versoin up, please contact to Minato or our distributor.

Remote

Remote menu is to switch between operation panel mode and remote mode for interface with external device. **Remote Select** allows the following two selections.

COM (RS232C)

USB

Select either one of them and press **START** key. Then M1950 changed to REMOTE mode.

For reset, press **RESET** key on M1950.

Each Operation Procedure

To set programming address <Single PAE mode>

MODE Device func PAE mode Single PAE Setting

Press mode key **MODE** key

Selet Device func

Mode menu	
[Device func]	Buffer operation
I / O command	System config
CF card	Rempte

Device function operation menu is displayed

Select PAE mode menu

Device function menu	
[PAE mode]	Read vcc
Verify mode	Function mode
Protect mode	Repeat mode

PAE mode operation menu is displayed

Select Single PAE mode

PAE mode menu	
Clear PAE mode	[Single PAE mode]
Multi PAE mode	

Single PAE Setting is displayed.

Single PAE Setting	OK -> [START] key
Start	[00000000]
End	003FFFFFF
Buffer	00000000

Address can be edited by **COM** key


Single PAE Setting	
Cursor (blinking)	
Single PAE Setting	OK -> [START] key
Start	[00000000]
End	003FFFFFF
Buffer	00000000

To process the setting, press **START** key

Confirmation buzzer sounds and initial operation menu is displayed.

When address is specified, PA is displayed on LCD.

Operation procezure



In case of M1950, address can be changed in every 16 byte.

To set auto programming address search <Multi PAE mode>

MODE Device func PAE mode Multi PAE mode

Press **MODE** key.

Select Device func

```
Mode menu
[ Device func ] Buffer operation
I/O command   System config
CF card       Remote
```

Device function operation menu is displayed.

Select PAE mode

```
Device function menu
[ PAE mode ] Read vcc
Verify mode   Function mode
Protect mode  Repeat mode
```

Select Multi PAE mode

```
PAE mode menu
Clear PAE mode   Single PAE mode
[ Multi PAE mode ]
```

Press **ENT** key. Then M1950 automatically scan valid data and the number of those sectors in the buffer.

```
Buffer scan   xxx/262
```

When buffer scan is completed, the number of targeted block is displayed.

```
Multi PAE mode set
valid block   OK -> [ START ] key
              xxx/262
```

The number of targeted block

This display shows the example of no targeted block.

```
Multi PAE mode clear
no valid block   OK -> [ START ] key
```

Operation proceure

Press **START** key to send the setting.

A buzzer sounds and initial menu is displayed on LCD.

BLANK	NO	Σ 256G/ 16b
i n t e l	RD38F3352LLZD	CD: 0E0BA4

To turn OFF PAE mode <Clear PAE mode>

MODE Device func PAE mode Clear PAE mode

Press **MODE** key

Select Device func

Mode menu	
[Device func]	Buffer operation
I/O command	System config
CF card	Remote

Device function operation menu is displayed.

Select PAE mode

Device function menu	
[PAE mode]	Read vcc
Verify mode	Function mode
Protect mode	Repeat mode

PAE mode operation menu is displayed.

Select Clear PAE mode

PAE mode menu	
[Clear PAE mode]	Single PAE mode
Multi PAE mode	

A buzzer sounds when Clear PAE mode is selected. Then formally set address is cleared. After automatic resetting, initial menu is displayed on LCD.

(PA is disappeared from the operation menu on LCD)

BLANK	NO	Σ256G/ 16b
intel	RD38F3352LLZD	CD: 0E0BA4

To set protect setting <Protect mode>

MODE Device func Protect mode

Press **MODE** key
Select Device func

Mode menu
[Device func] Buffer operation
I/O command System config
CF card Remote

Device function operation menu is displayed on LCD.
Select Protect mode.

Device function menu
PAE mode Read vcc
Verify mode Function mode
[Protect mode] Repeat mode

Protect operation mode is displayed.

Protect mode OK -> [START] key
Protect mode [NO PROTECT]

Select mode by left and right key
Press **START** key to execute the setting.
Confirmation buzzer sounds. Initial menu is displayed. It means that the setting is successfully completed.
Depending on the contents of the setting, different characters are displayed on LCD.

Each Protect Operation mode
NO: No operation
PO: Protect only
UP: Unprotect/Protect

BLANK NO Σ 256M 16b
i n t e l xxxxxxxxxxxxxx CD: xxxxxx

Enable protection per each sector <Protect setting>

MODE **Buffer operation** **Protect setting**

Protect setting per each sector can be edited.
Default setting is Unprotect for all sectors.

Press **MODE** key.
Select Buffer operation

Mode menu	
Device func	[Buffer operation]
I / O command	System config
CF card	Remot e

Buffer operation operation menu is displayed.
Select Protect setting

Buffer operation menu	
Buffer init	Buffer DUMP/ EDIT
Buffer swap	Check sum
[Protect setting]	Fast sum

Protect setting menu is displayed.
After moving blinking cursor to targeted protect # by arrow key, press **ENT** key

Cursor

Protect setting		OK -> [START]	
SA: 0/ 0047	0: ...	█
ADRS: 00000000	20:
MARKs: 8	40:

When **ENT** key is pressed, asterisk mark is displayed.
Asterisk means Protect
Dot means Unprotect

Asterisk mark means Protect area

Protect setting		OK -> [START]	
SA: 0/ 0047	0: ...	* █
ADRS: 00000000	20:
MARKs: 8	40:

When ENT key is pressed, cursor moves to the next column of asterisk.

To process the setting, press **START** key
Confirmation buzzer sounds. Initial menu is displayed. It means that the setting is successfully completed.

To set Verify voltage <Read vcc>

MODE **Device func** **Read VCC**

Press **MODE** key.

Select Device func

Mode menu	
[Device func]	Buffer operation
I / O command	System config
CF card	Remote

Device function operation menu is displayed.

Select Read VCC

Device function menu	
PAE mode	[Read vcc]
Verify mode	Function mode
Protect mode	Repeat mode

Read VCC menu is displayed.

In this operation display, each voltage can be changed.

Read vcc #copy:	PS1=2.9	PS2=0.0	PS3=0.0
BLANK	[2.90v]	0.00v	0.00v
VERIFY- L	2.90v	0.00v	0.00v
VERIFY- H	2.90v	0.00v	0.00v

By arrow key, cursor can be move to other item.

COM key to edit voltage

MODE key to set default value

When **START** key is pressed, a buzzer sounds. Then new value is set.

After a buzzer sounds, initial menu is displayed on LCD.

Only when voltage is changed, VC is displayed on LCD.

When read VCC is changed, VC is displayed.

BLANK	VCNO	Σ256M 16b
intel	RD38F3352LLZD	CD: 0E0BA4

PS1/PS2/PS3 of Read VCC is internal the source voltage of M1950. (Voltage during COPY)

To set verify pattern <Verify mode>

[MODE] [Device func] [Verify mode]

Press [MODE] key

Select Device func

Mode menu	
[Device func]	Buffer operation
I/O command	System config
CF card	Remote

Device function operation menu is displayed.

Select Verify mode

Device function menu	
PAE mode	Read vcc
[Verify mode]	Function mode
Protect mode	Repeat mode

Verify mode operation is displayed.

In this mode, the number of verify can be set.

Left and right key for default 2 Times 1 Time

Verify mode	OK -> [START] key
Verify count	[default]

Press [START] key to process the setting.

Confirmation buzzer sounds. Initial menu is displayed. It means that the setting is successfully completed.

BLANK	VF	NO	Σ256G/16b
intel	RD38F3352LLZD		CD: 0E0BA4

To enable contact /IC check <Function mode>

MODE Device func Function mode

Press **MODE** key

Select Device func

Mode menu	
[Device func]	Buffer operation
I / O command	System config
CF card	Remote

Device function operation menu is displayed.

Select Function mode

Device function menu	
PAE mode	Read vcc
Verify mode	[Function mode]
Protect mode	Repeat mode

Function operation mode is displayed.

Function mode	OK -> [START] key
contact check	[ON]
id check	ON

Left and right key to select ON/OFF.

Up and down key to select each item.

To set the selection, press **START** key.

Confirmation buzzer sounds. Initial menu is displayed.

Set repeat operation <Repeat mode>

MODE Device func Repeat mode

Press **MODE** key.

Select Device function

Mode menu	
[Device func]	Buffer operation
I/O command	System config
CF card	Remote

Device function operation menu is displayed.

Select Repeat mode

Device function menu	
PAE mode	Read vcc
Verify mode	Function mode
Protect mode	[Repeat mode]

Repeat mode operation is displayed.

Repeat mode	OK -> [START] key
Repeat mode	[OFF]

Left and right key for One Fail STOP all Fail STOP

Press **START** key to process the setting

Confirmation buzzer sounds. Initial menu is displayed. It means that the setting is successfully completed.


When other setting than OFF is set in Repeat mode, R is displayed on LCD.

When other setting than OFF is set, R is displayed on LED

BLANK	PA NO	R	Σ256M/16b
intel	RD38F3352LLZD		CD:0E0BA4

Buffer memory

M1950 handles buffer data in 8 bit (byte method). When 8 bit (byte method) in the buffer memory is converted to 16 bit (word method), little endian method is applied. Editing of data in the buffer is required in some case.



Buffer memory

To initialize buffer memory <Buffer init>

MODE **Buffer operation** **Buffer init**

Press **MODE** key.

Select Buffer operation

Mode menu	
Device func	[Buffer operation]
I/O command	System config
CF card	Remote

Buffer operation menu is displayed.

Select Buffer init

Buffer operation menu	
[Buffer init]	Buffer DUMP/EDIT
Buffer swap	Check sum
Protect setting	Fast sum

Buffer initialize operation is displayed.

Buffer initialize	OK -> [START] key
Start	[00000000]
End	00FFFFFF
Pattern	ALL FFH

By **COM** key, address can be edited.

In Pattern, data pattern can be edited.

Press left/right key for a selection.

Buffer initialize	OK -> [START] key
Start	00000000
End	00FFFFFF
Pattern	[ALL FFH]

Press **START** key to process the setting.

Press **START** key to execute the initialize of the buffer memory.

When this display is appeared, initialization is successfully completed.

Buffer initialize	
xxxxxxxx-xxxxxxxx : ALL FFH	
■■■■■■■■■■ COMPLETE ■■■■■■■■■■ 100%	

To edit buffer data <Buffer DUMP/EDIT>

MODE Buffer operation Buffer DUMP/EDIT

Caution prior to setting

Data editing in EDIT mode directly changes the data in the buffer memory in real time.
(No key operation such as **ENT**, **START** is required since the data is directly edited. **RESET** key does not allow you to recall the former data and reset key is good for reset.)

Press **MODE** key.
Select Buffer operation

Mode menu	
Device func	[Buffer operation]
I / O command	System config
CF card	Remote

Buffer operation menu is displayed.
Select Buffer DUMP/EDIT

Buffer operation menu	
Buffer init	[Buffer DUMP/EDIT]
Buffer swap	Check sum
Protect setting	Fast sum

Buffer DUMP/EDIT operation is displayed.
When cursor is located in ADRS area, that means M1950 is under DUMP mode.
Up/down key allows to change ADRS and left and right Key allows to change the position of cursor.

When cursor is located in ADRS area, that means M1950 is under DUMP mode

Buffer DUMP/EDIT	ADRS: 00000000
00000000:	FF FF FF FF FF FF FF FF
00000008:	FF FF FF FF FF FF FF FF
00000010:	FF FF FF FF FF FF FF FF

If you wish to change the data in the buffer memory,
You need to move to EDIT mode.
Press **COM** key to move to EDIT mode.
DUMP/EDIT mode can be changed by **COM** key.

Buffer memory

When cursor is located in this area, that means
M1950 is under EDIT mode.

Buf f er	DUMP	EDI T	ADRS: 00000000
00000000:	FF	FF FF FF FF FF FF FF	
00000008:	FF	FF FF FF FF FF FF FF	
00000010:	FF	FF FF FF FF FF FF FF	

To change data under EDIT mode, use up and down key. Left and right key allows you to change the position of the cursor.

Buffer DUMP/EDIT display consist of three interchangeable different displays.

Press **MODE** key to interchange among, byte display, 16 bit word display and 32 bit double word display.

Byte display (initial operatoin display of byte method)

16bit word display (initial operation display of 16 bit word method)

32bit double word display (initial operation display of 32 bit double word method)

Each operation is the same.

Remarks: Little endian is applied on 16 bit word display and 32 bit double word display.

Swap data in the buffer in each byte <Buffer swap>

MODE **Buffer operation** **Byte swap**

Press **MODE** key

Select Buffer operation

Mode menu	
Device func	[Buffer operation]
I/O command	System config
CF card	Remote

Buffer operation menu is displayed.

Select Byte swap

Buffer operation menu	
Buffer init	Buffer DUMP/EDIT
[Buffer swap]	Check sum
Protect setting	Fast sum

Buffer swap operation is displayed.

Buffer swap	OK -> [START] key
Start	[00000000]
End	00FFFFFF
Swap	BYTE

Up/down key to move to each item.

Left/right key to change address

At targeted time to be change, press **COM** to have blinking cursor to be displayed. Press up/down key to change the value and to left/right key to move to other item.

To confirm the change of the value, press **COM** key or **START** key.

By pressing either key, blinking cursor disappears. By left/right key, you can move to other item.

In Swap, byte can be set by left/right key.

When blinking cursor is gone, press **START** key to set new value.

Buffer memory

To swap data in the buffer in each word <Buffer swap>

MODE **Buffer operation** **Word swap**

Press **MODE** key.

Select Buffer operation

```
Mode menu
Device func      [ Buffer operation ]
I/O command     System config
CF card         Remote
```

Buffer operation menu is displayed.

Select Buffer swap.

```
Buffer operation menu
Buffer init      Buffer DUMP/EDIT
[ Buffer swap ]  Check sum
Protect setting  Fast sum
```

Buffer swap operation is displayed.

```
Buffer swap      OK -> [ START ] key
Start           [ 00000000 ]
End             00FFFFFF
Swap            BYTE
```

Up/down key allows you to move to each item.

In Swap, set WORD by left/right key.

```
Buffer swap      OK -> [ START ] key
Start           00000000
End             00FFFFFF
Swap           [ WORD ]
```

In Start/End, **COM** key to process the new setting.

Press **START** key to execute.

After the execution, setting complete is displayed.

```
Buffer swap
xxxxxxxx-xxxxxxx : WORD swap

■■■■■■■■■■ COMPLETE ■■■■■■■■■■100%
```

Other Operations.

To check the version of M1950 <M1950 Version>

MODE System config M1950 Version

To have current version of M1940 displayed on LCD

Press **MODE** key

Select System config

Mode menu	
Device func	Buffer operation
I/O command	[System config]
CF card	Remote

System config operation menu is displayed

Select M1950 Version

System config menu	
Format select	Remote setting
I/O channel select	Others mode
[M1950 Version]	System update

Currently installed version of M1950 is displayed on LCD.

M1950 VERSION	
Version	1.20C
Update	MAY-2006
Memory	512MB+0MB

Even if **DEV** key is pressed at this stage, the display will not go back to the former menu.
Press any other function key to go back to the former menu.

To have Check sum displayed <Check sum>

MODE

Buffer operation

Check sum

This function is to calculate the check sum of the buffer by software and have it displayed on LCD.
The address in the Check sum menu can be edited per one byte.

Press **MODE** key

Select Buffer operation.

```

Mode menu
Device func      [ Buffer operation ]
I / O command    System config
CF card          Remote
  
```

Buffer operation menu is displayed.

Select Check sum

```

Buffer operation menu
Buffer init      Buffer DUMP/ EDIT
Buffer swap      [ Check sum ]
Protect setting  Fast sum
  
```

Start and end address are displayed.

The displayed address is the buffer memory address of M1950 that is targeted to the selected device.

If PAE mode is valid, PAE setting is applied.

```

SUM calculation      OK -> [ START ] key
St ar                [ 00000000 ]
End                  003FFFFFF
  
```

Press **START** key to calculate the check sum.

```

SUM calculation...
PROGRESS ADRS=$xxxxxxxx
[-----]xxx%
  
```

```

SUM calculation
SUM=xxxxxxxx XOR=xx CRC=xxxxxxxx
■■■■■■■■■■ COMPLETE ■■■■■■■■■■100%
  
```

To have Fast sum displayed <Fast sum>

MODE **Buffer operation** **Fast sum**

This function is to calculate the check sum of the buffer by software and have it displayed on LCD.
The address in the Check sum menu can be edited per 16 byte (the first digit can not be changed).

Press **MODE** key.

Select Buffer operation

Mode menu	
Device func	[Buffer operation]
I / O command	System config
CF card	Remote

Select Fast sum

Buffer operation menu	
Buffer init	Buffer DUMP/ EDIT
Buffer swap	Check sum
Protect setting	[Fast sum]

Start and end address are displayed.

The displayed address is the buffer memory address of M1950 that is targeted to the selected device. If PAE mode is valid, PAE setting is applied.

SUM calculation	OK -> [START] key
Start	[00000000]
End	003FFFFFF

Press **START** key to have check sum displayed.

SUM calculating...	
PROGRESS	ADRS=\$xxxxxxx
[]	xxx%

SUM calculation	
SUM=xxxxxxx XOR=xx CRC=xxxxxxx	
■■■■■■■■■■	COMPLETE ■■■■■■■■■■100%

To skip Self Check <SELF CHECK>

MODE **System config** **Others mode**

Self check during booting the system can be set on/off.

Press **MODE** key.

Select System config

Mode menu	
Device func	Buffer operation
I/O command	[System config]
CF card	Remote

System config operation menu is displayed.

Select Others mode

System config menu	
COM setting	USB setting
Format select	Remote setting
I/O channel select	[Others mode]

Other Mode setting is displayed.

Move to SELF CHECK by up/down cursor

Other Mode setting	OK -> [START] key
SELF CHECK	[SKIP]
CRC MODE	CRC32
BUZZER	KEY+FUNCTION

Setting of SELF CHECK can be changed by left/right cursor.

To confirm the new setting, press **START** key.

When a buzzer sounds, the setting is completed.

After the setting is completed, initial menu is displayed.

BLANK	NO	Σ256G/16b
intel	RD38F3352LLZD	CD: 0E0BA4

To change the setting of CRC check <CRC MODE>

MODE System config Others mode

Press **MODE** key

Select System config

Mode menu	
Device func	Buffer operation
I/O command	[System config]
CF card	Remote

System config operation menu is displayed.

Select Others mode

System config menu	
COM setting	USB setting
Format select	Remote setting
I/O channel select	[Others mode]

Other mode setting is displayed.

Other Mode setting	OK -> [START] key
SELF CHECK	SKI P
CRC MODE	[CRC32]
BUZZER	KEY+FUNCTION

Move cursor to CRC MODE by up/down key.

To confirm the setting, press **START** key.

Confirmation buzzer sounds. The initial menu is displayed. That means the setting is completed.

There is no alphabetical display in initial menu.

BLANK	NO	Σ256G/ 16b
intel	RD38F3352LLZD	CD: 0E0BA4

To set a buzzer setting <BUZZER>

MODE System config Others mode

M1950 can sound a buzzer after each function is completed. The buzzer is ON as a default setting. If you wish to have buzzer turned off, you can make the setting as OFF.

Press **MODE** key

Select System config

Mode menu	
Device func	Buffer operation
I / O command	[System config]
CF card	Remote

System config operation menu is displayed.

Select others mode

System config menu	
COM setting	USB setting
Format select	Remote setting
I / O channel select	[Others mode]

Other mode setting is displayed.

Move to BUZZER by an up/down cursor.

Other Mode setting	OK -> [START] key
SELF CHECK	SKI P
CRC MODE	CRC32
BUZZER	[KEY+FUNCTION]

Setting of BUZZER can be changed by left/right cursor.
To confirm the new setting, press **START** key

When the setting is completed, initial menu is displayed.

BLANK	NO	Σ256G/ 16b
i n t e l	RD38F3352LLZD	CD: 0E0BA4

Operation of CF Card

To send data from CF Card to M1950

MODE

CF card

Press **MODE** key

Select CF card

```

Mode menu
Device func          Buffer operation
I/O command         System config
[ CF card ]         Remote
  
```

File select is displayed.

The file name in the CF card is displayed on LCD.

```

File select
PATH CF1:
NAME      : [ PAT000. BIN ]
SIZE      : 131,072 byte
  
```

By Right  key, stored file can be checked.

After selecting a targeted device, Press **ENT** or **START**

Then Store Address is displayed.

```

File select                      OK -> [ START ] key
PATH CF1:
NAME      : PAT000. BIN
Store Address: [ 00000000 ]
  
```

Set the start address of the file memory.

It can be edited by **COM** key.

When **START** key is pressed, data transfer is started.

When data transfer is completed, COMPLETE is displayed.

```

Load Pattern
file: PAT000. BIN
PROGRESS ADRS: $0001FFFF
■■■■■■■■■■■■■■■■■■■■ COMPLETE ■■■■■■■■■■■■■■■■■■■■■ 100%
  
```

That means data transfer is successfully completed.

Press any key to go back to initial display.

To send data from the buffer of M1950 to CF Card

MODE **CF card**

Press **MODE** key.


Select CF card

```
Mode menu
Device func      Buffer operation
I/O command     System config
[CF card]       Remote
```

File select is displayed.

The cursor shows the file name stored in CF card

```
File select
PATH CF1:
NAME      : [PAT000. BIN]
SIZE      : 131,072 byte
```

By Right  key a file name can be checked.

By keep pressing Right  key, Create File is displayed in the cursor.

```
File select
PATH CF1:
NAME      : [Create File]
```

Press **ENT** or **START** key.

Then Save File is displayed. File name is automatically assigned in NAME.

```
Save File          OK -> [START] key
PATH CF1:
NAME      : [PAT00x. BIN]
ADDRESS   : 00000000-007FFFFFFF
```

If you wish to change the file name and/or the extension, press **COM** key to edit.

Press **COM** key to have cursor displayed.

Cursor (under bar)

```
Save File          OK -> [START] key
PATH CF1:
NAME      : [PAT00x. BIN]
ADDRESS   : 00000000-007FFFFFFF
```

Left and right key is good for horizontal move.

Up/down key is good for changing numbers and characters.

Press **START** key to confirm the new setting.

Operation of CF Card

When the operation is completed, COMPLETE is displayed.

```
Save Pattern
file: PAT00x. BIN
PROGRESS ADRS: $0001FFFF
■■■■■■■■■■ COMPLETE ■■■■■■■■■■ 100%
```

This means data transfer is completed.

Press any key to go back to initial menu.

In NAME of file select, press **COM** key

```
File select
PATH CF1:
NAME      : [PAT000. BIN]
SI ZE     : 131,072 byte
```

The file name listing of CF card is displayed.

```
File select
CF1:
[PAT000. BIN] PAT000. MOT  PAT001. BIN
PAT001. MOT   PAT002. BIN  PAT002. MOT
```

Selection can be made by **ENT** or **START** key.

Remarks

In Name of File select display, pressing **COM** key displays the list of files in the CF card. You can select one file from the list. However, Create File can not be selected.

To access to Create File, go back to File select display and press **▼** key.

Before connecting to external device

M1950 is equipped with serial interface (RS-232C) and USB as standard interface to external device.

The following features of M1950 are available for data transfer to external device.

[Data in/out through RS-232C](#)

[Data in/out through USB](#)

- * Original USB driver is required to use USB
- * USB driver is included in the CD. (Please refer to USB set-up guide)
- * Standard USB available in the market can be used.

For data transfer between M1950 and external device, transfer condition must be set. The setting procedure that enables data transfer to the external device is described in this chapter.

USB Set Up Guide

This is the procedure of setting USB for the communication between M1950 and external device.
To install USB driver, please do not connect USB cable in USB port.

To install M1950 Installer

USB driver software can be executed from M1950usb_setup.exe in CD.


Execute M1950usb_setup.exe and click **Next(N) >** button in the menu. Then USB set-up is automatically start.

When menu is closed, that is the end of set-up.

Setting of programmer and USB

Connect USB cable to PC.

Then device is automatically detected.




Select **automatic software installation (recommended)**

Software installation is started.



Before connecting to external device

The following message for compatibility is displayed.



Click **Continue(C)**

The display indicates installaiotn of driver software is successfully completed.



Press **Complete** to end the task.

Display message may vary.

To Set RS-232C Interface <COM setting>

MODE **System config** **COM setting**

Set interface condition of RS-232C interface between M1950 and external device.

Press **MODE** key.

Select System config

Mode menu	
Device func	Buffer operation
I/O command	[System config]
CF card	Remote

System config operation menu is displayed.

Select COM setting

System config menu	
[COM setting]	USB setting
Format select	Remote setting
I/O channel select	Others mode

COM setting is displayed

COM setting	OK -> [START] key
BOARD RATE	[19200dps]
DATA BIT	7bit
PARITY	ODD

Up/down key to move cursor.

Left/right key to change the setting of each item.

To confirm the new setting, press **START** key.

By pressing START key, new interface condition is set and memorized.

The setting is valid even if the power is shut down.

Caution during remote operation

In M1950, ID check is executed during fundamental operation such as COPY, BLANK, etc. During panel operation, error is displayed when ID check error is detected on a device. Then the operation is stopped. According to LED lamp, operator can remove IC from the socket where error occurred. For remote operation, you can choose one of following setting. One is to output ID check error when a function is under process. The other is to output PASS/FAIL result of a device. (Remote emulation setting).

Remote Emulation Setting Mode

For remote operation of an auto handler, we recommend to use both M1940 mode and CK command for COPY, BLANK.

CK command: execute both contact check and ID check. Then output the result
Remove IC of which error is detected.

Fundamental function: execute COPY,BLANK, etc. Then output the result
Depending on the result, PASS IC could be placed on good tray and FAIL IC should be placed in NG tray.

Before connecting to external device

ID Check setting during fundamental operation <REMOTE EMULATION>

MODE → System config → Others mode

To set ID check (Yes/No) during fundamental operation such as (OP,VF,PG,etc)

Press **MODE** key.

Select System config.

Mode menu	
Device func	Buffer operation
I/O command	[System config]
CF card	Remote

System config menu is displayed.

Select Others mode

System config menu	
COM setting	USB setting
Format select	Remote setting
I/O channel select	[Others mode]

By up/down key, move cursor to REMOTE EMULATION

Make a selection by left/right key.

Other Mode setting	OK → [START] key
BUZZER	KEY+FUNCTION
REMOTE EMULATION	[M1940]
SET START COUNT	OFF

M1940 mode: Without ID check, fundamental operation is executed.

M1895 mode: After ID check is completed, fundamental operation is executed.

To confirm the new setting press **START** key.

Confirmation buzzer sounds. Then initial menu is displayed. The setting is completed.

BLANK	PA NO	Σ256M 16b
intel	RD38F3352LLZD	CD: 0E0BA4

Set format pattern <Format select>

[MODE] → [System config] → [Format select]

Select and set data format for data transfer between M1950 and external device by operation panel

Press [MODE] key.

Select System config

Mode menu	
Device func	Buffer operation
I/O command	[System config]
CF card	Remote

System config operation menu is displayed.

Select Format select.

System config menu	
COM setting	USB setting
[Format select]	Remote setting
I/O channel select	Others mode

Format select is displayed.

Format pattern can be selected by left/right key.

Format select	OK → [START] key
FORMAT [MOTOROLA- S(MOT)	

To confirm the new setting, press [START] key.

When a buzzer sounds, initial menu is displayed.

That is the end of setting.

BLANK	NO	Σ256G/ 16b
intel	RD38F3352LLZD	CD: 0E0BA4

When START key is pressed, the format is set and memorized. It will not be erased even if the power is turned off.

Before connecting to external device

To set input / output port <I/O channel select>

MODE → System config → I/O channel select

This is to set the interface between M1950 and external device for data command by I/O commands

Press **MODE** key.

Select System config

Mode menu	
Device func	Buffer operation
I / O command	[System config]
CF card	Remote

System config operation menu is displayed.

Select I/O channel select.

System config menu	
COM setting	USB setting
Format select	Remote setting
[I / O channel select]	Others mode

I/O channel select is displayed.

I / O channel select	OK → [START] key
Monitor channel	COM
Data I / O channel	[USB]

To confirm the new setting, press **START** key.

When a buzzer sounds, initial menu is displayed.

BLANK	NO	Σ256G/ 16b
intel	RD38F3352LLZD	CD: 0E0BA4

For data transfer <I/O command>

MODE → **I/O command**

Before carrying out this operation, connect a cable between the set port of M1950 and external device.

Read data through external device ("Transfer IN")

Press **MODE** key.

Select an I/O command.

Mode menu	
Device func	Buffer operation
[I / O command]	System config
CF card	Remot e

I/O command operation menu is displayed.

By left/right key, set Transfer "IN"

Then set buffer data start address (From File read ADRS),and

Buffer start address (To Buffer store ADRS),

And data end address (File read end ADRS).

I / O command	OK → [START] key
Transfer	[I N]
From File read ADRS	00000000
To Buffer store ADRS	00000000

To confirm the new setting, press **START** key.

When **START** key is pressed, data transfer is executed.

When the transfer is completed, a buzzer sounds.

Then initial menu is displayed.

That is the end of data transfer.

BLANK	NO	Σ256G/ 16b
i n t e l	RD38F3352LLZD	CD: 0E0BA4

Before connecting to external device

To output data to an external device ("Transfer OUT")

Press **MODE** key.

Select I/O command

Mode menu	
Device func	Buffer operation
[I / O command]	System config
CF card	Remote

I/O command operation menu is displayed.

By left/right key, set OUT for Transfer.

Then set buffer start address (From Buffer ADRS),

And buffer end address (To Buffer end ADRS),

The address of one device is set as Default.

I / O command	OK -> [START] key
Transfer	[OUT]
From Buffer ADRS	00000000
Buffer end ADRS	000FFFFF

To confirm the new setting, press **START** key.

When **START** is pressed, data transfer is executed.

When transfer is completed, a buzzer sounds. Then initial menu is displayed.

That is the end of transfer.

BLANK	NO	Σ256G/ 16b
i n t e l	RD38F3352LLZD	CD: 0E0BA4

Remote Operation of M1950

In this chapter, this chapter explains the operation how to control M1950 in remote through external USB or RS-232C cable is required for remote control.

When connection is completed, please make the following operation.

For the explanation, PC and key board are used as examples (PC: external terminal, Key board: input).

In this chapter, the following operation is explained.

Execution by operation panel

Execution by external terminal

Example of remote command

Symbols used in this manual (remote mode)

Displaying results of execution

Setting condition of remote mode <Remote setting>

MODE → System config → Remote setting

Press **MODE**

Select System config

Mode menu	
Device func	Buffer operation
I/O command	[System config]
CF card	Remot e

System config operation menu is displayed.

Select Remote setting.

System config menu	
COM setting	USB setting
Format select	[Remote setting]
I/O channel select	Ot hers mode

Remote setting operation menu is displayed.

Remot e sett ing	OK -> [START] key
ECHO	[OFF]
PROMPT	- - - -
ACK/ NCK	OFF

Each item can be accessed by up/down key.

You can select

One by left/right key.

To confirm the new setting, press **START** key.

A buzzer sounds. Initial menu is displayed.

BLANK	NO	Σ256G/ 16b
i nt el	RD38F3352LLZD	CD: 0E0BA4

Please refer to remote mode setting command for the data of the setting (RMD).

To make M1950 in REMOTE <Remote>

[MODE] → Remote

Execution by operation panel

In order to operate M1950 in remote, the mode of M1950 must be set as REMOTE.

In this page, the operation how to change M1950 in remote by operation panel is described.

Press [MODE] key

Select Remote.

Mode menu	
Device func	Buffer operation
I/O command	System config
CF card	[Remote]

Remote mode is displayed.

Remote mode	OK → [START] key
Remote Select	[COM]

By left/right key

COM (RS-232C)

USB (USB)

Either one of them from above selection can be set.

Select the port for the communication.

When [START] key is pressed, M1950 becomes remote mode. The following is the display message.

REMOTE

In the display of PC # (Prompt) is displayed.

By the setting of prompt display setting varies. (Refer to Remote setting)

Press [RESET] to go back to panel (local) operation.

Execution of remote mode by a command

It can be executed by keyboard operation.

Key operation	Ctrl+E Ctrl+E
ASCII CODE(HEX)	ENQ(05h) ENQ(05h)

By keyboard, input **Ctrl+E** **Ctrl+E**

When M1950 received this code, REMOTE is displayed on M1950. In the PC, # (prompt) is displayed.

This is the end of execution of remote mode.

Regarding targeted channel of remote:

When remote is executed by commands through external terminal, I/O channel that received **Ctrl+E** **Ctrl+E** becomes valid I/O channel.


When wrong input a made by a mistake, press Back Space on the keyboard to go back to the last area of input.

Before executing remoe mode, initial menu should be displayed on M1950. When any other menu is displayed, M1950 does not change to remote mode.


The display message varies depending on the setting of command prompt. (Please refer to Remote setting)

If there is any problem the operation up to now, please check the interface setting and setting of cables, etc.

Remote operation from external terminal




Remote operation from M1950



Format of remote command

Format of remote command



How to abbreviate the parameter

Parameter can be abbreviated. Action of a command can be different with parameter and without. Please refer to detail of the command in this manual.

In this page, the way how to abbreviate a part of commands with multiple parameters is discribed.

Basic format	Command,p1,p2,p3	CR
When only p1 should be changed	Command,p1	CR
When only p3 should be changed	Command, , ,p3	CR

Symbols used in this chapter (Remote mode)

This page defines the symbols as command input.

[n]	Output from external device without echo back from programmer
n	Output from external device with echo back from programmer (Echo back can be set as ON/OFF)
(LF)	Output from programmer (Echo back ON to output and OFF for no output)
<u>n</u>	Output from programmer
SP	Space code
CR	Carriage return (Enter key)
LF	Line feed
D1	XON
D3	XOFF

Display the result of command

In remote mode, in addition to the response of a command, the result of command can be output to external device.


There are two types of output format depending on the command.

(1) Commnd output for device execution


Device execution commnd	
Command	Contents of action
OP	COPY mode execution
CP	"
Z	ERASE mode execution
ER	"
B	BLANK mode execution
BL	"
V	VERIFY mode execution
VF	"
W	PROGRAM mode executoin
PG	"
OT	CONT command execution
CT	"
CK	Pre-check command

Device Status per each socket of M1950 as the results of device action is output to external device.

○ Output format of normal ending




○ Output format of abnormal ending




(2)Other command output format

Other command output format other than device execution command such as PAE, INI.

○ Output format of normal ending



○ Output format of abnormal ending



Setting of remode mode condition <RMD>

This operation is to confirm the condition of remote mode setting.

Some parameters are fixed valued as those are not supported by M1950.

To set it in remote, please refer to remote control of M1950.

Command format

RMD, p1, p2, p3, p4, p5, p6, p7

Parameter : Input value in px(within the parameter)
(Please refer to the following table)

Parameter	Action	Input Value	Setting	Input Value	Setting	Input Value	Setting	Fixed Value
p1	Echo Back	0	ON	1	OFF			
p2	Prompt	0	#	1	#CR LF	2	None	
p3	Time Out	0	OFF	1	TMO 1			0
p4	ACK/NCK	0	OFF	1	ON			
p5	Command Type	0	ON	1	m1900			1
p6	Buzzer	0	ON	1	OFF			
p7	Dammy Read	0	----	1	ON			1

p3: time out

p5: command type

p7: Dummy read can not be changed for M1950

To confirm the condtion setting of remote control

Please carry out the following operation to check the condition setting.

End of remote mode <E> <BY>

The following is the remote command operation to end remote mode.

To end remote mode by operation panel key of M1950, press **RESET** key.

Command format

E

or

BY

Parameter: No

E	C	R	(LF)
---	---	---	------

B	Y	C	R	(LF)
---	---	---	---	------

Termination command <Ctrl+D>

When this command is received during buffer memory data output, output is stopped. Then M1950 became ready to receive the next command.

Command format

Ctrl+D

Parameter: No

Help to output the list of commands **<H>p**

It is to output the list of commands

Command format

H

Parameter: No

HCR (LF)

<<< Example of output >>>

```
*****
* m1950 remote command *
*****

*** remote mode control ***
E,BY      : remote mode end          RMD      : remote config.
REV       : prom version display     H        : help message display
BS        : buffer size display       ^D       : cancel command
^E^E      : remote start

*** data in/out command ***
S,DF      : transfer format set      F,INI    : buffer mem initialize
P,PL,WD   : serial output            RL,RD    : serial input
RH        : parallel input
WP        : protect serial output     RP       : protect serial input
RPP       : protect parallel input

*** unit execute command ***
OP,CP     : copy command              OT,CT    : cont command
B,BL      : blank command             V,VF     : verify command
W,PG      : program command           Z,ER     : EEPROM erase command
CK        : contact check command

*** other command ***
BO,CS     : check sum (4 figures)     BO8,CS8  : check sum (8 figures)
N,DV      : device select             PCH      : protect mode change
L,LS      : buffer mem display        T        : buffer mem transfer
SCH       : buffer mem search         UNS      : buffer mem un_search
```

[illegible]

Device selection command <N> <DV>

This is a command to select or confirm the targeted device.

It is sent by a device code of device code list.

Please refer to basic operation of M1950 to set it by operation panel key of M1950.

Current set Device Code will be output without a parameter.

In P1, there should be characters/numbers in 6 digit.

Command format

N, p1

DV, p1

Parameter p1:Device Code(hex)

To confirm device
code

NC (LF)

090201 C L
R F

PASS, N<sub>P ; C L
P R F</sub>

D

V

C

R

(LF)

0 2 0 1 0 1 C L
R F

[illegible]

To set device code

N, **p**₁ **C**
R (LF)

[illegible]

DV, p1 CR (LF)

[illegible]

To execute COPY mode <OP> <CP>

To copy data from the IC set on socket #1 to the buffer memory of M1950.

Command format

OP

CP

Parameter: No

Status:

o(6Fh) Normal ending

x(78h) Abnormal ending

-(2Dh) No connection

The following two statuses are output when Remote Emulaotin is set as M1895 mode and ID error is detected.

. (2Eh): ID check PASS

? (3Fh): ID check FAILL

When this error occurred, programmer will stop before executing COPY.

OP^{CR} (LF)

PASS, OP^S_P o - - - - - S S S . C L
P P P j R F

CP^{CR} (LF)

PASS, CP^S_P o - - - - - S S S . C L
P P P j R F

To execute ERASE mode <Z> <ER>

This mode is to Erase data in the IC (EE-RPOM an Flash) set on socket #1 to #16

Command format

Z

ER

Parameter: No

Status:

o(6Fh) Normal ending

x(78h) Abnormal ending

-(2Dh) No device is detected

The following two statuses are output when Remote Emulaotin is set as M1895 mode and ID error is detected.

. (2Eh): ID check PASS

? (3Fh): ID check FAILL

When this error occurred, programmer will stop before executing ERASE.

Z^C_R (LF)

PASS, Z^S_P ^S_P o o o o o o o o o o o o - - - - ^S_P ^S_P ^S_P ; ^C_R ^L_F

ER^C_R (LF)

PASS, ER^S_P o o o o o o o o o o o o - - - - ^S_P ^S_P ^S_P ; ^C_R ^L_F

To execute BLANK mode <BL>

This mode is to make blank check (whether there is a data in IC set on socket #1 to #16 or not).

Command format

B

BL

Parameter: No

Status:

o(6Fh)	Normal ending
x(78h)	Abnormal ending
-(2Dh)	No device is detected.

The following two statuses are output when Remote Emulaotin is set as M1895 mode and ID error is detected.

. (2Eh): ID check PASS

? (3Fh): ID check FAILL

When this error occurred, programmer will stop before executing BLANK.

B	C	R
---	---	---

 (LF)

P A S S , B ^S_P ^S_P o o o o o o o o o o o o - - - - - ^S_P ^S_P ^S_P ; C L F

B	L	C	R
---	---	---	---

 (LF)

P A S S , B L ^S_P o o o o o o o o o o o o - - - - - ^S_P ^S_P ^S_P ; C L F

To execute PROGRAM mode <W> <PG>

This mode is to program data from the buffer memory to M1950 to IC set on socket #1 to #16.

Command format

W

PG

Parameter: No

Status:

o(6Fh) Normal ending

x(78h) Abnormal ending

-(2Dh) No device is detected.

The following two statuses are output when Remote Emulaotin is set as M1895 mode and ID error is detected.

. (2Eh): ID check PASS

? (3Fh): ID check FAILL

When this error occurred, programmer will stop before executing PROGRAM.

W_C_R (LF)

P A S S , W_P^S _P^S o o o o o o o o o o o o - - - - - _P^S _P^S _P^S . C L F

P G_C_R (LF)

P A S S , P G_P^S o o o o o o o o o o o o - - - - - _P^S _P^S _P^S . C L F

To execute VERIFY mode <V> <VF>

This mode is to verify the data in the buffer memory and IC set on socket #1 to #16.

Command format

V

VF

Parameter: No

Status:

o(6Fh) Normal ending

x(78h) Abnormal ending

-(2Dh) No device is detected

The following two status are output when Remote Emulaotin is set as M1895 mode and ID error is detected.

. (2Eh): ID check PASS

? (3Fh): ID check FAILL

When this error occurred, programmer will stop before executing VERIFY.

M**C****R** (LF)

PASS , VPS oooooooooooooooo - - - - - SPS . CRLF

M**F****C****R** (LF)

PASS , VFS oooooooooooooooo - - - - - SPS . CRLF

To execute CONTINUOUS mode <OT> <CT>

This is a recommended mode to program data from the buffer memory to IC.

Depending on the type of the device (whether electrically erasable device such as Flash/EE-PROM on which Erase is valid or not), internal operation flow varies.

For the detail, please refer to CONTINUOUS in the basic operation.

Command format

OT

CT

Parameter: No

Status

o(6Fh) Normal ending

x(78h) Abnormal ending

-(2Dh) No device is detected

The following two statuses are output when Remote Emulation is set as M1895 mode and ID error is detected.

. (2Eh): ID check PASS

? (3Fh): ID check FAIL

When this error occurred, programmer will stop before executing CONTINUOUS.

OT (LF)

PASS, OT_{SP} o o o o o o o o o o o o - - - - S_P S_P S_P ; C_R L_F

CT (LF)

PASS, CT_{SP} o o o o o o o o o o o o - - - - S_P S_P S_P ; C_R L_F

Setting ID check <SIG>

To make ID check and set it ON/OFF

Command format

SIG,P1

Parameter

p1: to set ID check ON/OFF

Status

0: ID check OFF

1: ID check ON (When device is changed, it is changed to ON)

To make ID check

SIG^C_R (LF)

SIG^S_P : ON , x x x x x x x , x x x ; C^L_R F

Device ID

PASS , SIG^S_P ^S_P ; C^L_R F

Device ID of the set device code is continuously output (the output number of byte is not fixed)

To set ID check

SIG^C_R (LF)

PASS , SIG ; C^L_R F

Pre-check command <CK>

MODE System config Others mode REMOTE EMULATION

This mode is to check the connection between device and socket.

Before executing COPY, BLANK, etc in remote mode, use this command to check the contact of IC and remove bad devices. The status is the same even if check function is changed by "REMOTE EMULATION" setting.

REMOTE EMULASION	Check function	
M1940	Contact check	ID check
M1895	Contact check	

Command format

CK

Parameter: None

Status:

o(6Fh) Normal connction

x(78h) Abnormal connection

-(2Dh) No connection

CK_R (LF)

P A S S , C K _P o o o o o o o o o o o o - - - - - _P _P _P , C L F

CK_R (LF)

? C K _P _P _P _P , o x x x - - - - - _P _P _P , C L F

Address Area Setting Command <MD> <PAE>

This command is to set the address area of basic operation.

By parameter, device start address, end address and buffer memory start address can be specified.

Selectable address varies by the the method of programming. For detail, please refer to the PAE mode of advance operation.

With no paramter, current setting is output.

By using expanded format, setting (ON/OFF) of Multi PAE mode can be set and checked.

Command format

MD, p1, p2, p3

PAE, p1, p2, p3

Parameter

p1: Start address of IC(hex)

“ - “ Default value:00

p2: Device end address(hex)

“ - “ Default value: device end address

p3: Buffer start address(hex)

“ - “ Default value:00

Remote Operation of M1950

Check and Confirm

MDCR (LF)

0 0 0 0 0 0 0 S P 0 0 0 F F F F S P 0 0 3 0 0 0 0 C R L F
 └────────────────┘ └────────────────┘ └────────────────┘
 p1: p2: p2:
 Device Start Address Device Start Address Buffer Start Address

[illegible]

P A E C R (LF)

0 0 0 0 0 0 0 ^S_P 0 0 0 F F F F ^S_P 0 0 3 0 0 0 0 ^C_R ^L_F

[illegible]

Set

M D, **p1** --- **p1**, **p2** --- **p2**, **p3** --- **p3** **C**
R (LF)

[illegible]

$$P, A, E, p_1, \dots, p_1, p_2, \dots, p_2, p_3, \dots, p_3, C_R \text{ (LF)}$$

[illegible]

Address Area Setting Command <MD> <PAE>

MD, PAE commands has expanded format. By using expanded format, setting (ON/OFF) of Multi PAE mode can be set and checked.

Expanded Command

*Expanded Command

DIS To clear address area

MLT To set Multi PAE mode

MOD To have PAE mode status displayed

To clear address area (default setting)

MD,DIS

PAE,DIS

To set Multi PAE mode

MD,MLT

MD,MLT

To have PAE mode status displayed

MD,MOD

PAE,MOD

Response

DIS : Standard mode (operation is valid for all data address of the device)

ENB : Single PAE mode
(Single PAE)

MLT 2 : Multi PAE mode
(Multi PAE)

Setting data format for transfer <S> <DF>

This mode enables to set and check the data format for transfer

Command format

S, p1

DF, p1

Parameter

p1:Data format #

0:MINATO HEX

1:————

2:INTEL HEX

3:————

4:————

5:MOTOROLA S

6:————

7:————

9:————

10:————

11:————

12:————

13:————

14:No Format

Check

S **C**
R (LF)

SP 0 2 SP SP SP I N T E L SP SP H e x CR LF

[illegible]

DFC (LF)

S P 0 5 S P S P M O T O R O L A S P S C L
F

[illegible]

Set

S, p1 p1 C_R (LF)

[illegible]

**D F , p1 p1 C
R (LF)**

[illegible]

Buffer memory size output <BS>

This mode is to have memory size of M1950 output.

Command format

BS

Parameter : None

BSR (LF)

4096M_Pbit_Pbuffer_R_F

[illegible]

Firmware Version Output <REV>

This mode is to have firmware version of M1950 displayed.

Command format

REV

Parameter : None

REV CR (LF)

S V S 1 . 30 S P S P S P S P S C L

[illegible]

Buffer memory data display <L> <LS>

This mode is to have data of buffer memory displayed.

By parameter, buffer memory start address and end address of the target can be specified.

Command format

L, p1, p2

LS, p1, p2

Parameter:

p1: Start address(hex)

Default value : 00

p2: End address(hex)

Default value: Buffer end address

In case of p1:0000;p2:002F (example of output)

L, 0, 2 F C_R (LF)

0000000^S_P03^S_P06^S_P0C^S_P18^S_P30^S_P60^S_PC0-----^S_P06^C_R^L_F

0000010_{SP}0C_{SP}18_{SP}30_{SP}60_{SP}C0_{SP}03_{SP}06.....S_{SP}18C_RL_F

0000020^S_P30^S_P60^S_PC0^S_P03^S_P06^S_P0C^S_P18.....^S_P60^C_R^L_F

[illegible]

In case of p1:0000;p2:00FF (example of output)

LS,OFFCR (LF)

0000000^S_P03^S_P06^S_P0C^S_P18^S_P30^S_P60^S_PC0-----^S_P06^C_R^L_F

0000010_S 0C_S 18_S 30_S 60_S C0_S 03_S 06_S S_P 18_R L_F

[illegible]

00000F0_S P 0C_S P 18_S P 30_S P 60_S P C0_S P 03_S P 06-----S_P 18C_R L_F

PASS, LS

Check sum display (four digits) <BO> <CS>


This mode is to output sum of data in the buffer memory of targeted address (or PAE area). The Check sum is four digits.

Command format

BO

CS

Parameter : None

[illegible]

CS_R (LF)

$$\underline{\text{DAC2}}_{\text{P}} \underline{\text{DAC2}}_{\text{P}} \underline{\text{DAC2}}_{\text{P}} \left. \vphantom{\underline{\text{DAC2}}_{\text{P}} \underline{\text{DAC2}}_{\text{P}} \underline{\text{DAC2}}_{\text{P}}} \right\} \cdots \underline{\text{DAC2}}_{\text{P}} \underline{\text{DAC2}}_{\text{R}} \underline{\text{DAC2}}_{\text{F}}$$

PASS, CS

Check sum displayed (8 digits) **<BO8>** **<CS8>**

This mode is to output sum of data in the buffer memory of targeted address (or PAE area). The Check sum is four digits.

Command format

B08

CS8

Parameter: None

B08C (LF)

3 6 6 D B 6 A 8 C L
R F

PASS, BO8 S P S P S P S P S P S P S P S P S P S P S , C L
R F

CS8 CR (LF)

3 6 6 D B 6 A 8 C L
R F

PASS, CS8 S P S S S S S S S S S S S S S S S S S S , C L
P R F

To initialize buffer memory <F> <INI>

This mode is to initialize the buffer memory of M1950 with certain data.

By parameter, the memory from targeted start address to end address is initialized by 8 byte data.

Command format

F, p1, p2, p3, p4, p5, p6, p7, p8, p9, p10

INI, p1, p2, p3, p4, p5, p6, p7, p8, p9, p10

Parameter

p1: Start address (hex)

Default value: 00

p2: End address (hex)

Default value Buffer end address

p3 to p10: default data (hex)

Default value: FF

$$[F, p_1, \dots, p_1, p_2, \dots, p_2, p_3, p_3, \dots, p_4, p_4, \dots, p_5, p_5, \dots, p_6, p_6, \dots, p_7, p_7, \dots, p_8, p_8, \dots, p_9, p_9, \dots, p_{10}, p_{10}, C_R]_{(L^F)}$$
[illegible]
$$I, N, I, p_1, \dots, p_1, p_2, \dots, p_2, p_3, p_3, p_4, p_4, p_5, p_5, p_6, p_6, p_7, p_7, p_8, p_8, p_9, p_9, p_{10}, p_{10}, C(R) \text{ (LF)}$$

PASS, INI S , C L
P ; R F

Data Search (Match) Command <SCH>

This mode is to search and match data (Max: 8 bit) in the buffer memory.

When specified data and buffer data is matched, the last address of the match is displayed. If there is no match, the next address of the end address is displayed.

By parameter, start address, end address and search data (max: 8 byte) can be specified.

Command format

SCH, p1, p2, p3, p4, p5, p6, p7, p8, p9, p10

Parameter:

p1: Search start address(hex)

Default value:00

p2: Search end address(hex)

Default value: buffer end address

p3-p10: Search data(hex)

Default value: FF

SCH, p₁ --- p₁, p₂ --- p₂, p₃ p₃, p₄ p₄, p₅ p₅, p₆ p₆, p₇ p₇, p₈ p₈, p₉ p₉, p₁₀ p₁₀ CR (LF)

$$\underline{\text{ADDR}}_{\text{P}} = \text{SP } 0000\text{A6C}_{\text{R}}^{\text{C}} \text{L}_{\text{F}}$$
[illegible]

Data Search (No Match) Command **<UNS>**

This command is to search unmatched data (one byte) in the buffer memory.

If there is any discrepancy between specified data and buffer data, the last address of the discrepancy is displayed. If there is no discrepancy, the next address of the end address is displayed. Then the mode ends.

By parameter, start address, end address and search data (one byte) can be specified.

Command format

UNS, p1, p2, p3

Parameter:

p1: Search start address (hex)

Default value: 00

p2: Search end address (hex)

Default value: buffer end address

p3: Search data (hex)

Default value: FF

UNS, p_1 ... p_1 , p_2 ... p_2 , p_3 p_3 CR (LF)

$$\underline{\text{ADDR}}_{\text{SP}} = \text{SP } 000106 \text{C}_{\text{R}} \text{L}_{\text{F}}$$

PASS, UNS

Data Transfer Command <T>

Data can be moved (copied) in the buffer memory

By parameter, start/end address of moving data and the first address of moving data (destination address) can be specified

Command format

T, p1, p2, p3

Parameter:

p1: start address(hex)

Default value: 00

p2: end address (hex)

Default value: buffer end address

p3: Destination address(hex)

Default value:00

$$\boxed{T}, \boxed{p_1} \dots \boxed{p_1}, \boxed{p_2} \dots \boxed{p_2}, \boxed{p_3} \dots \boxed{p_3} \boxed{CR} \text{ (LF)}$$
[illegible]

Serial I/F Data Output <P> <PL> <WD>

This is a command to output data through serial I/F in remote mode.

Buffer memory data of M1950 is output through Serial I/F according to Data Format set by S, DF command.

By parameter, buffer start/end address of output can be specified.

Command format

P, p1, p2

PL, p1, p2

WD, p1, p2

Parameter

p1: buffer memory start address (hex)

Default value: 00

p2: buffer memory output end address (hex)

Default value: buffer end address

Serial I/F Data Input <RL>

This is a command to input data through serial I/F in remote mode. This command makes M1895 to be ready for serial I/F input. The data sent through serial I/F is stored in buffer memory according to set data format.

By parameter, input data format, start/end address and buffer start address to store data can be specified.

Command format

RL, p1, p2, p3

Parameter:

p1: start address of the format (hex)



Default value: 00

p2: end address of the format (hex)

Default value: buffer end address

p3: buffer memory address (hex)

Default value: 00

[illegible]

Serial I/F Data Input <RD>

This is a command to input data through serial I/F in remote mode. This command makes M1895 To be ready for serial I/F input. The data sent through serial I/F is stored in buffer memory according to set data format.

By parameter, input data format, start/end address and buffer start address to store data can be specified.

Command format

RD, p1, p2

Parameter:

p1: start address of the format data(hex)

Default value: 00

p2: buffer memory address(hex)

Default value:00

$$\boxed{R} \boxed{D}, \boxed{p_1} \cdots \boxed{p_1}, \boxed{p_2} \cdots \boxed{p_2} \boxed{C} \boxed{R} \text{ (LF)}$$

Transfer format data from external device to M1950 through Serial I/F

[illegible]

To change Protect Mode Setting <PCH>

M1950 has three modes as operation related to data protection. According to parameter, protection mode can be changed. Please refer to Protect Mode in advance operatoin.

With no parameter, currently set protect mode is output.

Command format

PCH, p1

Parameter:

p1: Protect mode

0: No Operation

1: Unprotect/protect

2: Protect Only

Check

PCHC_R (LF)

S O S S S N O S O p e r a t i o n C L
P P P P P P P P R F

[illegible]

Set

PCH, p1 C_R (LF)

[illegible]

Protect Data Serial I/F Output <WP>

This command is to output protect data in remote mode. It is output to remote I/F.

When protect inf. of M1950 is converted to set Data Format such as (S, DF command), it is output through Serial I/F. It takes some minutes to out put protect data of the device through Serail I/F.

Command format

WP

Parameter: None

Example of output: To output 1st and 2nd protect data (intel format) of an IC which has 7 protect area

W P C (LF)

: 0 7 0 0 0 0 0 0 1 0 1 0 0 0 0 0 0 0 0 0 F 7 ^C_R ^L_F
 Sector: 0 1 2 3 4 5 6

```

: 0 0 0 0 0 0 0 1 F F C L
  _ _ _ _ _ _ _ _ _ _ R F

```

[illegible]

Protect Data Serial I/F Input <RP>

This command is to input protect data in remote mode. It is read through remote I/F.

This command makes M1950 ready to receive data through Serial I/F. Then M1950 receives protect data according to set Data format through Serial I/F.

By parameter, start address and end address of input data format can be specified.

Command format

RP, p1, p2

Parameter:

p1: start address of the format (hex)

Default value: 00

p2: end address of the format (hex)

Default value: Protect end address

$$\boxed{R} \boxed{P}, p_1 \cdots p_1, p_2 \cdots p_2 \boxed{\begin{smallmatrix} C \\ R \end{smallmatrix}} (LF)$$

Transfer protect data from external device to M1950 through Serial I/F

PASS, RP

List

List of Remote Command

Command	Action	Parameter
Ctrl+E Ctrl+E	To make M1950 in remote	
RMD	Setting of remote mode condition	p1, p2, p3, p4, p5, p6, p7, p8
E, BY	End of remote mode	
Ctrl+D	Termination command	
H	Help to output the list of command	
N, DV	Device selection command	p1
OP, CP	To execute Copy mode	
Z, ER	To execute Erase mode	
B, BL	To execute Blank mode	
W, PG	To execute Program mode	
V, VF	To execute Verify mode	
OT, CT	To execute Continuous mode	
SIG	Setting ID check	p1
CK	Pre-check command	p1
MD, PAE	Address area setting command	p1, p2, p3
S, DF	Setting data format for transfer	p1
BS	Buffer memory size output	
REV	Firmware version output	
L, LS	Buffer memory data display	p1, p2
BO, CS	Check sum display (4 digits)	
BO8,CS8	Check sum display (8 digits)	
F, INI	To initialize buffer memory	p1,p2,p3,p4,p5,p6 p7,p8,p9,p10
SCH	Data search (match) command	p1,p2,p3,p4,p5,p6,p7,p8,p9,p10
UNS	Data search (unmatch) command	p1, p2, p3
T	Data transfer command	p1, p2, p3
P, PL, WD	Serial I/F Data Output	p1, p2
RL	Serial I/F Data Input	p1, p2, p3
RD	Serial I/F Data Input	p1, p2
PCH	To change protect mode setting	p1
WP	Serial I/F protect data output	
RD	Serial I/F protect data input	p1,p2

List of special characters

The following input command is treated as special code. Even if echo back is ON, echo back will not occur.

ASCII code	Hex code	Process of M1950	ASCII code	Hex code	Process of M1950
NUL	00	Ignore	DLE	10	Ignore
SOH	01	Ignore	DC1	11	Process XON
STX	02	Ignore	DC2	12	Ignore
ETX	03	Ignore	DC3	13	Process XOFF
EOT	04	Termination command	DC4	14	Ignore
ENQ	05	Ignore	NAK	15	Ignore
ACK	06	Ignore	SYN	16	Ignore
BEL	07	Ignore	ETB	17	Ignore
BS	08	Backspace	CAN	18	Ignore
HT	09	Ignore	EM	19	Ignore
LF	0A	Ignore	SUB	1A	Ignore
VT	0B	Ignore	ESC	1B	Ignore
FF	0C	Ignore	FS	1C	Ignore
CR	0D	Command terminator	GS	1D	Ignore
SO	0E	Ignore	RS	1E	Ignore
SI	0F	Ignore	US	1F	Ignore
			DEL	7F	Backspace

List of error message

The following is the list of error message related to device process when an error occurred on 1950.

Error message	Contents of error	Remedy
Vcc over current	Over current Vcc is applied to IC.	Remove IC from socket adapter where red LED lits.
Illegal ID	Some socket adapters do not have IC or a socket adapter does not have an IC.	Set IC correctly onto socket adapter where red LED lits and start operation once again.
Empty Socket	Some socket adapters do not have IC or a socket adapter does not have an IC.	Check the socket where red LED lits.

List of error message of remote mode

The following is the list of error message of remote mode.

○ Error message during selfcheck

Error message	Cause	Remedy
M1950 SELF-CHECK !! FAIL DETECT!!	Self check error during boot -up.	Please reboot the programmer after making sure the power source is good. If it failed again, maintenance may be required.
!! FPGA INITIALIZING ... MISS !!		
SYSTEM ERROR : xx	System error	
ALPG INTERRUPT DETECT MEMORY ERR : xxxxxxxx	Memory check error is occurred	
ALPG INTERRUPT DETECT REASON:????????????	Programming timing circuit error	
OVER CURRENT DETECT REASON : A:xxxx B:xxxx	Programming timing circuit error	

○ Abnormal action

Cause	Remedy
Nothing is displayed.	Please reboot the programmer after making sure the power source is good. If it failed again, maintenance may be required.
No LED lits.	
No buzzer sounds.	Please check the buzzer by the panel operation

○ Error message during Read/Write device

Error message	Cause	Remedy
! CONTACT CHECK FAILED !	Bad contact between the socket and IC or no IC on socket Red LED of the socket lits.	Check the socket
! OVER-CURRENT DETECT !	Over current on IC is detected. Red LED of the socket lits.	Remove the device
ID CHECK FAILED !	Different device other than device code set is detected. Red LED of the socket lits.	Remove the device
Multi PAE mode clear no valid block	No data is found after buffer scan for PAE mode.	Load data to program

○ Error message of CF card and data transfer

Error message	Cause	Remedy
NO DRIVE	CF is not installed.	Check CF card.
UNKNOWN FORMAT	There is no file which can not be read by M1950.	Check the file format of CF card Applicable format are 1. Intel. Hex 2. Motorola. mot 3. Binary. bin
FILE FULL	There is no space to save data in CF card	Change CF card
MISSING	Since there was not enough memory space left in CF card, all data was not saved.	
FORMAT READ ERROR	Read error occurred during data transfer	Check the data
FORMAT SUM CHECK ERROR	Check sum error occurred during data transfer.	Check the sum of the error record
FORMAT AREA OVER ERROR	Transferred data is larger than buffer memory of M1950	Add offset on the read start address.

○ Error message of device code set

Error message	Cause	Remedy
Device not Select!!	Device code is not set	Select a device code
Device Table not found!!	Device code is not available	Make version up of M1950
Device module not found	No module for the device is not available.	Make version up of M1950

○ Error message of remote

Error code	Contents of error	Cause
90	Check Sum Error	Check sum error occurred during data transfer
91	Format Error	Read error occurred during data transfer.
F0	Illegal Command	Illegal command is input.
F1	Parameter Error	Wrong parameter is input.
F2	Invalid Function	Invalid command is executed. (Executing Erase on EPROM)
F3	Multi PAE mode Error	Multi PAE Setting error (No data was found during bad block scan for Multi PAE.

Explanation of Quick Reference Manual

The following is the outline of the quick reference manual.

[VAL] and [SEL] in the menu


■ [VAL]

Value that can be numerically changed such as address, Vcc.

COM key to change it.

[SEL]

Selection that can be chosen.

 key to select it.

Explanation of each function

1. Item

Menu item in each mode

2. Selection

Selecton in each menu

3. Default value


Defalut value prior to shipment


4. Contents

Brief explanation of each item

5. Influence of the setting to the other operatoin

It relates to the following operation

Setting is not changed=

Setting is changed =

1. Update

It related to the version up of M1950

2. Re-boot of M1950

It related to turn off/ on of M1950 to re-boot.

3. Device selection

It related to the device selection

4. Reset

It related to open the same menu once again

5. Function

Function that is not supported by certain devices

Depending on device = ★

All device is supporting the function = ☆

Function is either ★ or ☆

Quick Reference

Update

Return on

Device selection

Resetting

Function

☆

x

x

x

x

Item	Selection		Default	Contents of item	
SETTING PAE					
Clear PAE mode	MODE	Device func	PAE mode	Clear PAE mode	☆ x x x x
None	None		None	Setting of PAE is cleared	
Single PAE mode	MODE	Device func	PAE mode	Single PAE mode	Operation is decided by START button ☆ ○ x x x
Start	[VAL]	Setting as optional		Depend on device	Start address is indicated
End	[VAL]	Setting as optional		Depend on device	End address is indicated
Buffer	[VAL]	Setting as optional		Depend on device	Start Buffer address is indicated
Multi PAE mode	MODE	Device func	PAE mode	Multi PAE mode	Operation is decided by START button ☆ x x x x
None	None		No effect	Load area is set scanning memory	
Setting Verify VCC					
Read VCC	MODE	Device func	Rerd VCC	Operation is decided by START button Initialized by Mode button ☆ ○ x x x	
BLANK	[VAL]	Setting as optional		Depend on device	VCC is changed when blank is operated
VERIFY _L	[VAL]	Setting as optional		Depend on device	VCC is changed when Verity _{1, 2} is operated
VERIFY _H	[VAL]	Setting as optional		Depend on device	VCC is changed when Verity _{3, 4} is operated
Setting of Verify VCC					
Verify Mode	MODE	Device func	Verify Mode	Operation is decided by START button ☆ ○ x x x	
Verify Count	[SEL]	[default]	[1 Time] [2 Time]	[default]	Number of verify is changed
Setting of Contact/ID check					
Function Mode	MODE	Device func	Function mode	Operation is decided by START button ☆ ○ x x x	
contact check	[SEL]	[ON] [OFF]	[ON]		Contact check is effective or not
id check	[SEL]	[ON] [OFF]	[ON]		ID check is effective or not
Setting of Repeat Mode					
Repeat Mode	MODE	Device func	Repeat mode	Operation is decided by START button ☆ ○ x x x	
Repeat mode	[SEL]	[OFF]	[One Fail STOP] [all Fail STOP]	[OFF]	Repeat Mode is set
Output of device information					
Monitor Mode	MODE	Device func	Monitor mode	Operation is decided by START button ☆ ○ x x x	
monitor	[SEL]	[ON] [OFF]	[OFF]		Device information of Nand is output for external terminal
Transfer of data					
I/ O command for xxx					
(Incase that setting of Transfer is IN) MODE I/ O command Operation is decided by START button ○ x x x x					
Transfer	[IN] [OUT]	[IN]		Direction of data transfer	
From File read ADRS	[VAL]	Setting as optional		[00000000]	Start address of data
To Buffer store ADRS	[VAL]	Setting as optional		Depend on device	Start address of buffer
File read end ADRS	[VAL]	Setting as optional		Depend on dimension of mdmory	End address of buffer
(Incase that setting of transfer is out) MODE I/ O command Operation is decided by START button ○ x x x x					
Transfer	[IN] [OUT]	[OUT]		Direction of data transfer	
From Buffer ADRS	[VAL]	Setting as optional		Depend on device	Start address of buffer
Buffer end ADRS	[VAL]	Setting as optional		Depend on device	End address of buffer
-----	None				

Quick Reference

Item	Selection	Default	Contents of item
------	-----------	---------	------------------

Buffer initialize

Buffer initialize	MODE	Buffer operation	Buffer init	Operation is decided by start button	☆	x	x	x	x
Start	[VAL]	Setting as optional		Depend on device					Start address of Initialize is specified.
End	[VAL]	Setting as optional		Depend on device					End address of Initialize is specified.
Pattern	[SEL]	[ALL FFH] [ALL 00H] [03060C,18...] [0000FF,FF...]		[ALL FFH]					Pattern of Initialize is selected.

Buffer DUMP/EDIT

Buffer DUMP/EDIT	MODE	Buffer operation	Buffer DUMP / EDIT	Real time change	☆	○	○	x	x
ADRS	[VAL]	Setting as optional		[00000000]					
Data	[VAL]	Setting as optional		FFH					

BYTE/WORD Swap

Buffer swap	MODE	Buffer operation	Buffer swap	Operation is decided by start button	☆	x	x	x	x
Start	[VAL]	Setting as optional		Depend on device					Start address is specified.
End	[VAL]	Setting as optional		Depend on device					End address is specified.
Swap	[SEL]	[BYTE] [WORD]		[BYTE]					BYTE/WORD mode is changed.

Check sum

Check sum	MODE	Buffer operation	Check sum	Operation is decided by start button	☆	x	x	x	x
Start	[VAL]	Setting as optional		Depend on device					Start address of check sum is specified.
End	[VAL]	Setting as optional		Depend on device					End address of check sum is specified.

Fast sum

Fast sum	MODE	Buffer operation	Fast sum	Operation is decided by start button	☆	x	x	x	x
Start	[VAL]	Setting as optional		Depend on device					Start address of check sum is specified.
End	[VAL]	Setting as optional		Depend on device					End address of check sum is specified.

Protect setting

Protect setting	MODE	Buffer operation	Protect setting	Operation is decided by start button ON/OFF by ENT	★	○	x	x	x
SA	[SEL]			Depend on device					Sector protect number is displayed.
ADRS	[SEL]	[*] [.]		Depend on device					Sector protect address is displayed.
MARK	[SEL]	[*] [.]		[.] Protect OFF					Protect ON or OFF is specified.

Setting Protect Mode

Protect Mode	MODE	Device func	Protect mode	Operation is decided by start button	★	○	x	x	x
Protect mode	[SEL]	[NO PROTECT] [UNPROTECT / PROTECT] [PROTECT ONLY]		[NO PROTECT]					Protect function is specified.

Access Remote Mode

Remote mode	MODE	Remote	Operation is decided by start button	○	x	x	x	x	x
Remote Select	[SEL]	[COM] [USB]		[COM]					Remote access point is specified.

M1950 Version-up

Update menu	MODE	System config	System update	Operation is decided by start button	☆	x	x	x	x
Load from	[SEL]	[CF card] [COM] [USB] [ROM] [INITIALZE]		[CF card]					System version-up
M 1950 update	[SEL]	[AUTO] [BOOT] [MONITOR] [SYSTEM] [FPGA] [DEVICE TABLE] [DEVICE PROGRAM] [MODULE] [not support] [BACKUP DATA]		[AUTO]					

Quick Reference

Item	Selection	Default	Contents of item
------	-----------	---------	------------------

Setting of alata transfer

COM setting		MODE → System config → COM setting	Operation is start button	☆ ○ ○ ○ ○
BORAD RATE [SEL]	[115200 bps] [57600 bps] [38400 bps] [19200 bps] [9600 bps]	[115200 bps]	Selection of Baud Rate	
DATA BIT [SEL]	[8bit] [7bit]	[8bit]	Selection of data bit	
PARITY [SEL]	[NON] [EVEN] [ODD]	[NON]	Parity bit	
STOP BIT [SEL]	[2bit] [1bit]	[2bit]	Stop bit	
FLOW CONTROL [SEL]	[XON OFF] [NO CTRL]	[XON OFF]	Flow control	

USB code setting

USB setting		MODE → System config → USB setting	Operation is start button	☆ ○ ○ ○ ○
ID CODE [VAL]	Setting as optional	[00000]	USB code is indicated.	

Data Format

Format select		MODE → System config → Format select	Operation is start button	☆ ○ ○ ○ ○
FORMAT [SEL]	[NO - FORMAT(BIN)] [MINATO (MIN)] [INTEL HEX (HEX)] [MOTOROLA -S (MOT)]	[MOTOROLA -S (MOT)]	Transfer format is selected.	

Remote setting

Remote setting		MODE → System config → Remote setting	Operation is start button	☆ ○ ○ ○ ○
ECHO [SEL]	[ON] [OFF]	[ON]	Echo back is executed or not..	
PROMPT [SEL]	[#] [#CRLF] [---]	[#]	Prompt is expressed..	
ACK / NCK [SEL]	[ON] [OFF]	[OFF]	Responsence	
BUZZER [SEL]	[ON] [OFF]	[ON]	Remote buzzer	

I/O channel select

I/ O channel select		MODE → System config → I/O channel select	Operation is start button	☆ ○ ○ ○ ○
Monitor channel [SEL]	[OFF] [COM] [USB]	[OFF]	Selection of device information output channel.	
Data I/O channel [SEL]	[OFF] [COM] [USB]	[OFF]	Selection of data input/output channel.	

Other Mode setting

Other Mode setting		MODE → System config → Others mode	Operation is start button	☆ ○ ○ ○ ○
SELF CHECK [SEL]	[NO SKIP] [SKIP]	[NO SKIP]	Execution of self check when power supply is started	
CRC MODE [SEL]	[CRC 32] [CRC 16]	[CRC 32]	CRC32 or CRC16 is switched when sum is calculated.	
BUZZER [SEL]	[KEY +FUNCTION] [FUNCTION] [KEY] [OFF]	[KEY +FUNCTION]	Setting of system buzzer.	
REMOTE EMULATION [SEL]	[M1940] [M1895]	[M1940]	Setting of Pre-check operation when remote is operated.	
SET START COUNT [SEL]	[OFF] [0.1S] ...[100S]	[OFF]	Setting of waiting time when device operation is started.	

VERSION information

M 1950VERSION		MODE → System config → M1950 VERSION	Operation is start button	☆ × × × ×
M 1950VERSION	None	Depends on system version	Version information is displayed.	

CF card

File select		MODE → CF card	Operation is start button	☆ × × × ×
NAME [SEL]	Depend on CF card	Depend on CF card	Display of file select	
Store Address [VAL]	Setting as optional	[00000000]	Address of buffer start address.	

Item of NAME when Create File is selected.

Save File		MODE → CF card	Operation is start button	☆ × × × ×
NAME [SEL]	Create File	Depend on CF card	Display of file select	
Store Address [VAL]	Setting as optional	[00000000]	Buffer start address	